
AIR FORCE AERO PROPULSION LAB WRIGHT-PATTERSON AFB OHIO F/G 21/4
VISCOSITY MEASUREMENTS OF POTENTIAL HIGH DENSITY HYDROCARBON FU--ETC(U)
JUN 76 H R LANDER, A E STROUSE
AFAPL-TR-76-17
NL AD-A031 902 UNCLASSIFIED NL 10F2 AD31902





VISCOSITY MEASUREMENTS OF POTENTIAL HIGH DENSITY HYDROCARBON FUEL BLENDS

FUELS BRANCH
FUELS AND LUBRICATION DIVISION

JUNE 1976

TECHNICAL REPORT AFAPL-TR-76-17 FINAL REPORT 1 FEBRUARY 1973 - 30 JUNE 1975



Approved for public release; distribution unlimited

AIR FORCE AERO PROPULSION LABORATORY AIR FORCE WRIGHT AERONAUTICAL LABORATORIES AIR FORCE SYSTEMS COMMAND WRIGHT-PATTERSON AIR FORCE BASE, OHIO 45433

NOTICE

When Government drawings, specifications, or other data are used for any purpose other than in connection with a definitely related Government procurement operation, the United States Government thereby incurs no responsibility nor any obligation whatsoever; and the fact that the government may have formulated, furnished, or in any way supplied the said drawings, specifications, or other data, is not to be regarded by implication or otherwise as in any manner licensing the holder or any other person or corporation, or conveying any rights or permission to manufacture, use, or sell any patented invention that may in any way be related thereto.

This report has been reviewed by the Information Office (ASD/OIP), and is releasable to the National Technical Information Service (NTIS). At NTIS, it will be available to the general public, including foreign nations.

This technical report has been reviewed and is approved for publication.

Project Engineer

Lead Technician

FOR THE COMMANDER

Chief, Fuels Branch

Fuels & Lubrication Division

Copies of this report should not be returned unless return is required by security considerations, contractual obligations, or notice on a specific document.

REPORT DOCUMENTATION PAGE	READ INSTRUCTIONS BEFORE COMPLETING FO
AFAPL-TR-76-17 (9) Final Rep	t. Dec 73-Dec
Viscosity Measurements of Potential High D Hydrocarbon Fuel Blends	Final Report, December 1973 to December 1974
20 A 1	6. PERFORMING ORG. REPORT NUM
Herbert R. Lander, Jr. Alfred E. Strouse	ux 76 (@) 134
9. PERFORMING ORGANIZATION NAME AND ADDRESS Air Force Aero Propulsion Laboratory	10. PROGRAM ELEMENT PROJECT
Fuels Branch (SFF) Wright-Patterson AFB, Ohio 45433	30480547
11. CONTROLLING OFFICE NAME AND ADDRESS Air Force Aero Propulsion Laboratory	12. REPORT DATE
Fuels Branch (SFF	June 1976 13. NUMBER OF PAGES
Wright-Patterson AFB, Ohio 45433 14. MONITORING AGENCY NAME & ADDRESS(If different from Controlling	Office) 15. SECURITY CLASS. (of this report)
Vadua (17) 05/	UNCLASSIFIED
13448 (1045)	15a. DECLASSIFICATION/DOWNGRA
Approved for public release; distribution un	nlimited.
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the abstract entered in Block 20, if displaying the state of the	fferent from Report)
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if display the abstract entered in Block 20, i	lierent from Report)

DD 1 JAN 73 1473


EDITION OF 1 NOV 65 IS OBSOLETE

SECURITY CLASSIFICATION OF THIS PAGE(When Date Entered)

Using the Model 17 Weissenberg Rheogoniometer, the viscosity of pure RJ-5 and blends of RJ-5 and other hydrocarbons was determined over a temperature range from -65 F to #0 F. The hydrocarbons evaluated as viscosity improvers when added to Shelldyne-H include toluene, JP-4, methylcyclohexane, tetralin, decalin, RJ-4 (tetrahydro-methylcyclopentadiene dimer) and isobutylbenzene. The concentrations studied were 5, 10, 25, 35 and 50 weight percent diluent in RJ-5.

Toluene blends were found to be the most effective in reducing low viscosity while retaining volumetric heating values at significantly high levels.

It is concluded that considerable progress is possible in the high density missile fuel area through the blending of hydrocarbon components. Present high density fuels, such as RJ-5 can be tailored to yield fuels with properties which are more adaptable to suitable system designs for low temperature application and yet have significantly more volumetric energy (higher density) than conventional hydrocarbon fuels



FOREWORD

This report contains the results of an effort to alleviate the high viscosity of RJ-5 (Shelldyne-H®) at low temperatures by means of various hydrocarbon diluents. The in-house research was performed in the Fuels Branch of the Air Force Aero Propulsion Laboratory, Air Force Systems Command, Wright-Patterson Air Force Base, Ohio, under Project 3048, Task 304805, and Work Unit 30480547. The effort was conducted by Mr. Herbert R. Lander, Jr., of AFAPL/SFF and Mr. Alfred E. Strouse of AFAPL/TFF during the period of 1 February 1973 to 30 June 1975.

TABLE OF CONTENTS

SECTION			PAGE
30A9 T	INTR	ODUCTION	191913
II	STAT	EMENT OF THE PROBLEM	4
III	EQUI	PMENT TO DESCRIPTION OF A STATE OF THE PROPERTY AND A STAT	10
IV	PROG	HE NEW LOOP 및 BEST AND BETT CONTROL OF SELECTION OF SELE	20
N V	PROG	RAM RESULTS	24
VI	DISC	USSION - A STATE OF THE STATE OF THE PROPERTY	33
VII	CONC	LUSIONS (AND	47
VIII	RECO	MMENDATIONS	49
		The Effect of People Assume on the Weignstey of Serious Signiture will be placed	
APPENI	DIX A,	Calculations for Determining Viscosity on the Cone and Plate Viscometer	51
APPENI	DIX B,	Thermal Expansion of the Weissenberg Rheogoniometer	57
APPEN	DIX C,	Viscosity Determination Procedures for the R17 Weissenberg Rheogoniometer	62
APPENI	DIX D,	Weissenberg Rheogoniometer Viscosity Data Sheets	70
APPENI	DIX E,	Viscosity of Shelldyne-H®Blends at Various Temperatures	96
APPENI	DIX F,	Calculated Densities and Heats of Combustion for the Various Blends	106
REFER	ENCES	Transported Special carrier transport to describe	124

ILLUSTRATIONS

FIGURE		PAGE
1	Viscosity of Shelldyne-H® (HNBD Dimer) as a Function of Temperature	2
2	Photograph of AFAPL Weissenberg Rheogoniometer and Ancillary Equipment	11
3	Photograph of the Measuring Section of the Weissenberg Rheogoniometer	12
4	Chromatogram of Shelldyne-H®, Lot Nr. LR-11410-103	21
5	The Effect of Temperature on the Viscosity of Various Shelldyne-H®/Toluene Blends	25
6	The Effect of Temperature on the Viscosity of Various Shelldyne-H®/JP-4 Blends	26
ª 7	The Effect of Temperature on the Viscosity of Various Shelldyne-H / Methylcyclohexane Blends	27
8	The Effect of Temperature on the Viscosity of Various Shelldyne-H /Tetralin Blends	28
9	The Effect of Temperature on the Viscosity of Various Shelldyne-H / trans-Decalin Blends	29
10	The Effect of Temperature on the Viscosity of Various Shelldyne-HB / TH-MCPD Dimer Blends	30
11	The Effect of Temperature on the Viscosity of Various Shelldyne-H /Isobutylbenzene Blends	31
12	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H / Toluene Blends	34
13	Viscosity at Various Temperatures persus Volumetric Heat of Combustion for Shelldyne-HB / JP-4 Blends	35
14	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H /Methylcyclohexane Blends	36

ILLUSTRATIONS

FIGURE	, Ison to be a supposed on the first state of the continuous states and the continuous states and the continuous states and the continuous states are st	PAGE
15	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H / Tetralin Blends	37
16	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H /t-Decalin Blends	38
17	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H /TH-MCPD Dimer Blends	39
18	Viscosity at Various Temperatures versus Volumetric Heat of Combustion for Shelldyne-H (B) /Isobutylbenzene Blends	40
s 19	Viscosity at -65°F for Various Diluent/Shelldyne-H® Blends and their Effect on Heat of Combustion (Vol.)	41
20	Viscosity at -40°F for Various Diluent/Shelldyne-H® Blends and their Effect on Heat of Combustion (Vol.)	42

TABLES

TABLE		PAGE
1	Chemical and Physical Requirements for Fuel, Ramjet, Grade RJ-5	350073
11	Effect of 8 Day Soak at -65°F on HNBD Dimer -2 and -3 Mixtures	9
111	Characteristics of Test Platens and Torsion Bar	16
IV	Rheogoniometer Results on Brookfield Viscosity Standards	16
V	Effect of Gap Setting Errors on Accuracy	18
VI i	Chemical and Physical Analyses of Shelldyne-H [®] , Lot Nr. LR-11410-103	22
VII	Program Test Fluids	23
VIII	The Heat of Combustion (Vol) of Various Diluent/ Shelldyne-H Blends which have Viscosities of 1000 Centipoise at -65°F	45
IX	The Heat of Combustion (Vol.) of Various Diluent/ Shelldyne-H Blends which have Viscosities of 500 Centipoise at -65°F	45
X	The Heat of Combustion (Vol) of Various Diluent/ Shelldyne-H Blends which have Viscosities of 1000 Centipoise at -40°F	46
XI	The Heat of Bombustion (Vol.) of Various Diluent/ Shelldyne-H Blends which have Viscosities of 500 Centipoise at -40°F	46

SECTION I

The principle problem associated with the use of Shelldyne-H[®] (RJ-5) as a missile fuel is its high viscosity, particularly at 0°F and below^{*}. The viscosity of this potential fuel increases more than two orders of magnitude between 0°F and -65°F. The steepness of the semi-logarithmic plot of viscosity as a function of temperature is shown in Figure 1, where the viscosity of Shelldyne-H[®] is plotted versus temperature. At -65°F, the viscosity of the fuel is increasing at approximately 3000 centipoise per °F. These data were obtained on the cone and plate Weissenberg Rheogoniometer, which will be discussed later in this report.

Chemically, Shelldyne-H can be succinctly described as a mixture of the hydrogenated dimers of norbornadiene (HNBD dimers). This material has been produced in batch quantities by Shell Development Company, formerly of Emeryville, California, to meet the RJ-5 specification. The chemical and physical requirements of this tentative specification are outlined in Table 1. The properties which best differentiate this fuel from others is the high density (specific gravity is 1.08) and its extremely high viscosity, particularly at lower temperatures. All other properties are quite similar to those of most other aircraft and missile hydrocarbon fuels. Of major concern to the designer is relief of some of the low temperature problems associated with using Shelldyne-H . These points will be discussed in later sections.

^{*} References (1,2,3,24,25,30)




TABLE I
PROPOSED MILITARY SPECIFICATION FOR RJ-5

<u>Requirements</u>	Limits	Test Method ASTM Standard
Distillation Temperature, °F (°C), Min. Initial boiling point 10 percent point 20 percent point 50 percent point	470 (243.3)	D86
90 percent point		
End Point, °F (°C), Max	525 (273.9)	
Distillation Residue, Volume %, Max	1.5	
Distillation Loss, Volume %, Max	1.5	
Gravity at 60°F API Max (Sp. Gr. Min)	-0.5 (1.08)	D287
Existent Gum, Mg/100 M1, Max	7.0	D381
Potential Residue, 16 Hrs Aging, Mg/100 Ml, Max	14.0	D873
Sulphur, Total, Weight Percent, Max	0.05	D1266
Mercaptan Sulphur, Weight Percent, Max	0.001	D1219 or
		D1323
Pour Point, °F, Max Heating Value	-65	D97
Net heat of combustion, Btu/lb, min	17,750	D2382
Net heat of combustion, Btu/gal, min	160,000	
Viscosity, Centistokes, Max		
at -65°F	20,000	
at -30°F	1,400	
at 100°F	15	
Aromatics, Volume Percent, Max	1.0	D1319
Olefins, Volume Percent, Max	1.0	D1319
Flash Point, °F, Min	150	D93
Copper Strip Corrosion, ASTM, Max	No. 1	D130
Thermal Stability		
Change in pressure drop in 5 hrs, in Hg, max Preheater deposit code, max	3 2	D1660
Particulate Matter		
Mg/Liter, max F.O.B. origin deliveries	1.0	D2276
Mg/Liter, Max F.O.B. destination deliveries Fuel System Icing Inhibitor	2.0	
Volume percent, min	0.10	
Volume percent, max	0.15	
Bromine number, max	1.0	D1159

SECTION II STATEMENT OF THE PROBLEM

In the short space of one decade, the status of the hydrocarbon fuel known as Shelldyne-H® has risen from a laboratory curiosity to the baseline fuel for the Advanced Strategic Air Launched Missile (ASALM). Volume limited strategic cruise missiles of this type must use denser fuels (or more energy per given volume) if they are to attain greater range. Projected performance requirements of these systems put a high premium on range, time-to-target and packaging. When applied in combination, these factors tend to favor air-breathing engines for non-ballistic systems. These requirements, quite naturally, have stimulated ramjet and turbojet missile development programs. In order to meet these stringent performance requirements, fuels with high volumetric heating values must be used. The reason, therefore, for the evolution of Shelldyne®, Shelldyne-H®, and eventually the RJ-5 specification (Table 1) is not surprising since it has the highest density of any hydrocarbon which remains a fluid down to -65°F. The lower temperature limit of -65°F is currently required for all air launched missiles.

Shelldyne-H® type fuels are going to play a greater role in the future plans of both the Air Force and Navy. Efforts are currently underway to make RJ-5, or modifications thereof, more meaningful to the engine and systems designers.

Over the last ten years, approximately 10,000 gallons of Shelldyne® or Shelldyne-H® have been produced by Shell Oil Company affiliates, both in this country and in Europe. The process for producing this material has been

patented (4-14) and articles in the open literature have delved into the chemistry of the process (15-21). Shelldyne-H® is a registered name of a hydrocarbon produced by hydrogenating the dimers of norbornadiene (HNBD). Until approximately five years ago, the fuel was not hydrogenated (Shelldyne®) and because of reactive double bonds was subject to instability during storage. The Shell Development Company has produced approximately 6700 gallons of Shelldyne-H® for AFAPL sponsored engine and fuel system development programs (22,23). In September 1973, Shell Oil Company licensed Ashland Oil Company exclusive rights to produce Shelldyne-H®.

As pointed out initially, the great potential of Shelldyne-H[®] as a missile fuel is blighted by its high viscosity, particularly at sub-zero temperatures. This problem is one which can be alleviated either by system design or by fuel modification. Fuel system design incorporating either expulsion techniques or tank heating have been proposed as possible solutions to the flow problems at low temperatures (24,25). More conventional fuel systems would probably rely more on the modified Shelldyne-H[®]. The potential of diluting Shelldyne-H[®] with lighter hydrocarbons is investigated in this effort and reported in this report. The effect of the various diluents on not only the viscosity but the density and heat of combustion of Shelldyne-H is considered and evaluated.

Another problem in using Shelldyne-H® at low temperatures, which became evident in the past year, is the tendency of some batches of fuel to freeze at temperatures above -65°F. This phenomenon is related to the conformation of the dimers which make up Shelldyne-H® and the fact that some batches of

material have higher freezing points than others. For the most part, the higher freezing points have not been detected in conventional laboratory tests because the material can be supercooled. The supercooling is a paradoxical phenomena which might be related to many things including the rate of cooling. In the case of a fast cooling rate, the viscosity of Shelldyne-H R is thought to increase so rapidly that the individual molecules are unable to rearrange themselves into the appropriate crystalline order before solidification. Crystallization might then occur after some time at this low temperature or might even occur upon being heated as the molecules become more mobile but are still below the actual freezing/melting point of the material. The possibility of any freezing occurring at temperatures above -65° must be understood and alleviated if Shelldyne-H® is to be used in air launched systems. Supercooling to below the actual melting point of Shelldyne-H® cannot be relied upon since the presence of such miscellaneous potential nucleation sites as dust, water crystals, sharp metallic surfaces, etc., cannot be completely eliminated from fuel systems. Therefore, the true melting point of Shelldyne-H® must be lowered to a temperature below the minimum system requirement which is normally -65°F for Air Force air launched systems.

Shelldyne-H[®] is composed of at least three major dimers which make up more than 98% of the material. The mixture of these hydrocarbons produces a eutectic which has a melting point considerably lower than the pure dimers. By using a preparative gas chromatographic technique, chemists at AFAPL were able to separate the three major dimers that make up Shelldyne-H[®]. In order to

justify future research into the chemical modification, it was of interest to see whether any combination of two or more of these dimers would not freeze above $-65^{\circ}F$. Numbered according to their gas chromatographic elution time, the dimers of Shelldyne-H $^{\bigcirc}R$ were found to freeze at approximately 92°F, 41°F and 46°F, respectively. Normally, Shelldyne-H $^{\bigcirc}R$ will contain between 10-20% of dimer -1, 16-22% of dimer -2 and 55-75% of dimer -3. Since the last two dimers had the lower freezing points, a preliminary program was initiated to determine whether mixtures of only these two dimers could form eutectics which would meet the -65°F (and lower) melting/freezing point restriction.

The series of mixtures of only dimer -2 and -3 were made and tested (Monsanto Research Corporation contract AF33615-72-C-1071). Using weight percent concentrations from 0 to 100% in approximately 10% increments, these mixtures were stored for up to eight days in a controlled low temperature bath at -65°F. The results of this test are summarized in Table II. After eight days at -65°F, only mixtures containing 29.9, 40.3, 49.5 weight percent of dimer -2 were still liquids. Since not all batches of Shelldyne-H® which contain the three major dimers freeze above -65°F, research efforts are currently underway to ascertain which concentrations of the three dimers are required. When this is determined, production reaction conditions could be adjusted to produce the desired concentration of the dimers which have true melting points below -65°F. The Shelldyne-H® used in this program was composed of the three major dimers and had a melting point below -65°F.

The principal objective of this research program was to study the effect of various hydrocarbon fluids on reducing the low temperature viscosity of

Shelldyne-H[®]. It was also of interest to determine the effect of the diluent on the density and energy of the Shelldyne-H[®]. Previous (1,2) efforts had indicated that considerable reductions could be obtained in viscosity with only small losses in density and energy. Shell Development Company, under AF contract, studied the effects of different hydrocarbons (methylcyclohexane, decalin, dimethanodecalin, n-heptane and JP-7 fuel) in reducing the viscosity of Shelldyne-H[®] fuel at temperatures from -65°F to 73°F. Concentrations as small as 1 weight % diluent resulted in substantial reduction of the viscosity of Shelldyne-H[®] without any significant changes in other properties of the fuel. Of the diluents tested in the Shell program, methylcyclohexane had the greatest effect in reducing the viscosity of Shelldyne-H[®].

TABLE 11

EFFECT OF 8 DAY SOAK AT -65°F ON HNBD DIMER -2 AND -3 MIXTURES

SAMPLE NUMBER	DIMER -2, WT %	DIMER -3, WT %	RESULTANT PHASE*
a to mammilet a 1	of anivab ridl .	100	enili se ta tyropici. Do S
2	9.9	90.1	S
_3	20.9	79.1	S
4	29.9	70.1	L
orderm of them	40.3	59.7	eto i nage offe ad "
feat 16 me literal	49.5	50.5	to part the amora r
264 Alub 'sae	60.0	40.0	suspens ent stod al
8	70.1	29.9	Selinemel something
erese um intencina	81.9	18.1	S S
10	89.8	10.2	T moon far a laster
The The section	100	na evith one sector	s come a solution

L - PHASE

^{*} S - SOLID

SECTION III EQUIPMENT

The experimental portion of this program was carried out on the Model R17 Weissenberg Rheogoniometer which was modified to measure liquid viscosities at temperatures down to -100°F or below. This device is a refinement of a design by Weissenberg and is manufactured by Sangamo Controls, Ltd., Bognor Regis, England, and is distributed in this country by the Technidyne Corporation, Louisville, Kentucky.

The rheogoniometer was developed as a research instrument to measure stress vs. rate of shear dependence at every point in the fluid under test in both the tangential and normal planes. For this program, only the ordinary tangential data were obtained since the liquids were simple Newtonian fluids. Figure 2 is a photograph of the rheogoniometer and associated equipment. The main components are from left to right, the drive unit (including motor, gearbox and drive shaft), the main body, instrument controls, and recording equipment. The measuring section of the rheogoniometer is very precisely engineered and is shown within the main body in Figure 3. Not shown in these figures are the modifications needed to get test conditions down to -65°F. This was accomplished by using cold nitrogen to cool the platens which were enclosed in the temperature control chamber which is shown in an opened position in Figure 3. The nitrogen actually served a dual purpose of cooling the platens and providing a dry, inert atmosphere around them. The gas passed into the test chamber through special gas inlets. This gas was cooled by heat exchange in a 25 foot coil of 5/16 inch 0D copper tubing submerged in a dewar of liquid nitrogen. Temperature control within the




Figure 2. Photograph of AFAPL Weissenberg Rheogoniometer and Ancillary Equipment




Figure 3. Photograph of the Measuring Section of the Weissenberg Rheogoniometer

chamber was achieved by adjusting the flow rate of cold nitrogen. The temperature of the test platens was detected by a copper-constantan thermocouple embedded in the outer surface of the top platen. The temperature was indicated on a Digital Voltmeter, Series X-3, manufactured by Non Linear Systems, Inc., Del Mar, California.

The basis of the rheogoniometer is the single cone and plate viscometer which is pictured in the center of Figure 3. This device has evolved into a very useful instrument for both industrial and research organizations. It has the versatility and sensitivity to measure the viscosity of fluids from 10^8 poise down to the thinnest of materials. It has been reported (26) that the viscosity of air has been measured with 100 times more sensitivity because of the electronic equipment and associated ultra violet recorder. Thus, viscosities as low as 1 \times 10⁻⁶ to 1 \times 10⁻⁵ poise can be measured; therefore, the instrument has a range of approximately 10^{14} . The range of shear rates available in this instrument is from 10^{-3} to 10^4 sec⁻¹, although it is, of course, not possible to use high shear rates with thicker materials or to obtain measurable readings with low shear rates and thin materials.

The measuring section of the rheogoniometer is very precisely engineered (Figure 3). The operation of the instrument is relatively simple with a two-way drive box translating the continuous rotational drive from the gear box from the horizontal axis to a vertical axis through a gear reduction connected to a worm and wheel. Through this worm and wheel, the vertical shaft drives the lower cone. The viscous drag is transmitted through the sample to the upper platen which is attached to the rotor of an air-bearing

torsion head. This allows a small, but virtually frictionless circular movement of the upper platen against a calibrated torsion bar, and this movement is detected by a linear displacement inductive transducer capable of measuring down to 0.1 micron of platen movement.

The fluid to be tested is sheared between the rotating cone and the fixed flat platen. The basic shear-rate shear-stress relation of the fluid is obtained from the measurement of the rotational speed and the torque required to drive the platen. Since the angle between the cone and plate is small, the shear stress will be very nearly uniform throughout the fluid. Frederickson (27) reported that the percentage difference in shear stress between cone and plate for cone angle less than 4° was less than 0.5%; for the AFAPL 2° cone angle, the difference in shear stress was only 0.12%. Therefore, the assumption that shear stress and, hence, shear rate and apparent viscosity are uniform throughout the fluid, is an excellent one. For the Newtonian fluids studied in this program, the apparent viscosity is the same as the absolute viscosity.

The flow equations for the cone and plate viscometer have been developed (26,28) and the results of these developments are described in Appendix A.

In the research program, the Weissenberg Rheogoniometer, which had been procured originally for metal slurried fuel evaluation, was set up and adjusted according to the instruction manual (26).

Procedures for calibrating the electronics, calibrating the displacement transducers, changing the torsion bars and changing and aligning the plates were followed as outlined in the manual.

The testing performed on this program was carried out on one set of platens, using only one torsion bar. Pertinent data on these test specimens are outlined in Table III.

Calibration tests were performed on Brookfield Engineering Laboratory, Inc. Viscosity Standard Fluids. The purpose of these tests was to determine the accuracy of the instrument on fluids of known viscosity. The results of these initial tests are outlined in Table IV. The standard fluids cover the viscosity range of interest and all tests were performed at room temperature.

With the exception of the "11900.0 centipoise" standard, the data obtained on the AFAPL rheogoniometer was generally within 5% of the Brookfield reported values. Since most of the data obtained in this program would be below 5000 centipoise, the test set-up seemed adequate from an accuracy standpoint.

Another area of concern in running the cone and plate rheogoniometer is the effect of "gap setting" on test results. Based on the theory of plate and cone viscosity, it is vital for the sake of accuracy that the point of the cone just touch the center of the flat plate. This, of course, would disturb the torque reading; therefore, the point of the cone is truncated to prevent interference. This gives negligible error since the torque produced at the center of the plate is immeasurable; however, it is vitally important to adjust the gap as accurately as possible so that the imaginary tip of the cone would just touch the center of the plate. The amount of truncation in microns is determined by the manufacturer and is etched in the back of each cone; this measurement is used in setting the gap. The procedure used in "gap setting" is outlined in the instruction manual (26). Since most of our testing would be

TABLE III

CHARACTERISTICS OF TEST PLATENS AND TORSION BAR

<u> Item</u>	Description		
Cone Platen	Number 1140, diameter 5 cm, actual cone angle 2° 0' 22" - Apex of cone - 91 microns		
Flat Platen	Number 865, diameter 5 cm		
Torsion Bar	Number 6/26 Constant, K _T = 1.851 X 10 ¹ dyne-cm microns		

TABLE IV

RHEOGONIOMETER RESULTS ON BROOKFIELD VISCOSITY STANDARDS

Test Temperature: 78°F Cone Platen Nr : 1141 Flat Platen Nr : 865 Torsion Bar Nr : 6/26

Brookfield Standard Fluid Viscosity Centipoise @ 77°F	AFAPL Test Viscosity Centipoise @ 78°F	% Error
5.1	(1 y 2) 11 (1 avous) (alderosas est. 5.1	0
9.0	9.05	+0.5
49.0	49.85	+1.7
96.0	99.70	+3.9
470.0	482.78	+2.7
1010.0	1012.79	+0.3
4750.0	4880.28	+2.7
11900.0	12954.25	+8.9
31200.0	32535.16	+4.3

carried out at various temperatures from ambient to -65°F, it was necessary to determine the effect of thermal expansion on "gap setting" and, in turn, the effect of "gap setting" error on test results. It was reported (26) that the gap between the truncated cone and flat plate would close at about 0.69 microns per °F when the plates were heated. This figure is only approximate depending mainly on the rate and pattern of cooling of the instrument, particularly, air bearing rotor and lower extension piece immediately above and below the temperature control chamber. Since our program was primarily concerned with low temperature viscosity, care had to be exercised so that the gap was accurately set at each test temperature.

A series of tests was performed on the rheogoniometer using the test platens and torsion bar where the gap was set at 91 microns at 75°F and the test chamber temperature was, stepwise, reduced to -65°F. The change in 'gap setting' was then determined using the special gap setting knob which is unique to the Model R17 Rheogoniometer. It was found that the 'gap setting' increased by 0.82 microns per °F as the temperature was lowered from 75°F to -65°F; this agrees closely with the 0.69 microns per °F reported by the manufacturer.

In order to ascertain the effect of any "gap setting" error on test accuracy, a series of tests was performed on the 470 centipoise "Brookfield Standard" silicone fluid. These tests were performed at 78°F and outlined in Table V. These data substantiate the fact that errors in "gap setting" could appreciably alter the accuracy of viscosity measurements on the cone and plate rheogoniometer. With the platens and torsion bar used in this program,

AFAPI -76-17

it is safe to assume that if the gap setting is within \pm 20% of the designated value, an accuracy of 5% is possible.

TABLE V

EFFECT OF GAP SETTING ERROR ON ACCURACY

Test Platens: 5 cm (2° cone angle)

Torsion Bar: 2/26

Test Fluid: 470 centipoise silicone fluid

Test Temperature: 78°F

Gap Setting, Microns	Viscosity, Centipoise	% Error in Gap Setting	% Error in Measured Viscosity
91	482.78		99 zen 21 0 1 30 253
75	503.77	-17.58	+4.35
50	535.26	-45.05	+10.87
91	482.78	0	0 1000
116	459.17	27.47	-4.89
141	419.80	54.95	-15.00

For viscosity measurements in this program, care was exercised in setting and adjusting the gap for each test temperature. This was done by obtaining data on the effect of temperature on 'gap setting'; these data were then used to develop a plot of 'gap setting' adjustment versus temperature. This plot and the operative procedure used at various temperatures are outlined in Appendix B.

1

Considerable confusion exists concerning the units used to express viscosity. In this program, the metric system was used. In this system, the unit of absolute viscosity is the poise which is equal to 100 centipoise. The poise has the dimensions of dyne seconds per square centimeter, or of grams per centimeter/second. In order to circumvent any confusion concerning vicosity units, the centipoise is used exclusively in this report. As a point of reference, the kinematic viscosity is the ratio of the absolute viscosity to the mass density. In the metric system, the unit of kinematic viscosity is stoke. The stoke has dimensions of square centimeters per second and is equal to 100 centistokes. The kinematic viscosity in centistokes of any material at a given temperature is equal to the absolute viscosity in centipoise of the material at the given temperature divided by the mass density (grams per cubic cm) of the material; again, at the given temperature.

In addition to the viscosity data, the densities and heating values of each of the blends were calculated. The goal of the program was to evaluate the effects of dilution on the viscosity and density of Shelldyne-H fuel in order to formulate more suitable fuels from the fuel system design aspect.

SECTION IV PROGRAM

With proper dimer ratio, pure Shelldyne-H (will remain a homogeneous fluid down to temperatures below -65°F. The batch of Shelldyne-H (used in this program was Shell Development Company's Batch Nr LR-11410-103 which did not freeze above -65°F. Figure 1 is a plot of the viscosity of this fluid as a function of temperature. Figure 4 is a chromatogram of this batch of material; the composition of the fluid is discussed in Reference 29, where it was reported that there were 10.3%, 16.8% and 72.0% of the three major dimers and 0.9% of a fourth component that eluded from the column between the second and third major components. The chemical and physical analyses of this batch, as reported by Shell Development, are outlined in Table VI.

The objective of this program was to investigate the effect of various hydrocarbons on reducing the high viscosity of Shelldyne-H[®]. Since Shelldyne-H[®] is of interest as a fuel, it was also of interest to determine the effect of hydrocarbon diluents on the heat of combustion. The hydrocarbons, used as diluents in this program, are presented in Table VII, together with the supplier and the grade. These materials were blended in concentrations of approximately 5, 10, 25, 35 and 50 weight percent in Shelldyne-H[®] and the viscosities of the resulting blends were measured at selected temperatures between -65°F and 70°F. As mentioned previously, all testing was conducted using the 5 cm platens with 2° 0' 22" cone angle; the smallest torsion bar (Nr 6/26) available was also used in all the testing reported herein.




FIGURE 4. Chromatogram of Shelldyne-H®, Lot Nr LR-11410-103

TABLE VI SHELLDYNE-H ANALYSIS

(Lot LR-11410-103)

Density at 68°F, gms/cc	1.079
Viscosity at 68°F, centipoise	20.6
Refractive Index at 68°F	1.5413
Flash Point, °F (Penski-Martin Closed Cup)	240
Pour Point, °F (ASTM D-97)	-60°F
Heat of Combustion (net), Btu/lb	17,908
% Carbon (Wt)	90.07
% Hydrogen (Wt)	9.87
Water, ppm	14
Thermal Stability (ASTM D-1660, 500°F)	0 Rating
ASTM Distillation	
Initial Boiling Point	500
5% Distilled, °F	511
95% Distilled, °F	518
End Point, °F	525
Recovery, %	99

TABLE VII

PROGRAM TEST FLUIDS

ds no FLUID () 2300ds 81.50 V	GRADE	SUPPLIER
Methylcyclohexane	High Purity	Shell Development Co.
Decahydronapththalene (decalin)	High Purity	Shell Development Co.
Tetrahydronaphthalene (tetralin)	Purified	Fisher Scientific Co.
Toluene	Reagent	J. T. Baker Chemical
Cis-decalin	99%	Chemical Samples Co.
Trans-decalin	99%	Chemical Samples Co.
Isobutylbenzene	99%	Chemical Samples Co.
Tetrahydro- methylcyclopentadiene dimer (TH-MCPD)	High Purity	Ashland Oil Company
Tetrahydro-norbornadiene	High Purity	Shell Development Co.

raysiting between the temperatures of indiff and ififf, all the blends

SECTION V PROGRAM RESULTS

There is no reliable method for estimating the viscosity of liquid mixtures (31); therefore, all concentrations of interest had to be measured experimentally on the rheogoniometer. The viscosity data sheets obtained on the mixtures are included in Appendix D. These data were reduced into conventional viscometric terms and these have been tabulated in Appendix E. Appendix A outlines the mathematical procedure necessary to reduce the rheogonometric measurements into viscosities.

Figures 5-11 present the viscosities of the various blends as affected by temperature. For aid in determining the viscosity reduction produced by each diluent, the viscosity of "pure" Shelldyne-H $^{\textcircled{R}}$ is also plotted on each figure. The diluents significantly reduced the viscosity of Shelldyne-H $^{\textcircled{R}}$, particularly at the lowest temperatures, even at low concentrations. As an example, the blend containing 5 weight percent toluene (Figure 5) reduced the -65°F viscosity of Shelldyne-H $^{\textcircled{R}}$ by a factor of about / (from 31,457 centipoise to 4,489.9 centipoise).

Although the viscosity of Shelldyne-H[®] is reduced by the diluents over the entire range of test temperatures, the most significant effects are at the lower temperatures. The viscosity of Shelldyne-H[®] increases an order of magnitude between the temperatures of -40°F and -65°F; all the blends tested had less significant rises for this temperature range. It should be apparent to the missile designer that any arbitrarily selected temperature limit could seriously affect his choice of fuel.

FIGURE 5. The Effect of Temperature on the Viscosity of Various Shelldyne-HB/Toluene Blends




FIGURE 6. The Effect of Temperature on the Viscosity of Various Shelldyne-H/JP-4 Blends.




FIGURE 7. The Effect of Temperature on the Viscosity of Various Shelldyne-H/Methylcyclohexane Blends.




FIGURE 8. The Effect of Temperature on the Viscosity of Various Shelldyne-H/Tetralin Blends.




FIGURE 9. The Effect of Temperature on the Viscosity of Various Shelldyne-H/trans-Decalin Blends




FIGURE 10. The Effect of Temperature on the Viscosity of Various Shelldyne-H/TH-MCPD Dimer Blends.





FIGURE 11. The Effect of Temperature on the Viscosity of Various Shelldyne-H/Iso-butylbenzene (IBB) Blends.



The diluents with the lowest viscosity in the pure state (i.e., MCH, toluene, and JP-4) had the most significant effect on the viscosity of Shelldyne-H[®]. Since these materials had the lowest density, they would also have the greatest effect on lowering the density of the mixture; this would also result in lower volumetric energy. Therefore, any attempt to completely evaluate the effect of the diluents on Shelldyne-H[®] as a fuel candidate, must include the effect of dilution on density and energy as well as viscosity. The next section will discuss these comparisons.

Only the trans-decalin isomer was tested over the range of concentrations in Shelldyne-H $^{\textcircled{R}}$ (Figure 9) rather than the cis-isomer, because the trans-isomer seemed to have the greater effect on viscosity reduction (Appendix E, Figure E-10).

SECTION VI DISCUSSION


In order to evaluate the effect of the diluents on the potential of Shelldyne-H R as a missile fuel, the analysis must include more than low temperature viscosity measurements. The attractiveness of Shelldyne-H R as a fuel is its density which results in a high volumetric heating value. Therefore, the heating value or net heat of combustion for each blend was estimated for each binary mixture and these data were plotted in Figures 12 through 18. The heat of combustion data were determined as outlined in Appendix F. The viscosity data in Figures 12 through 18 are those determined in this program.


The thinner hydrocarbons, such as methylcyclohexane and JP-4 are very effective diluents but they have low densities and low volumetric heating values which reduce these values when mixed with Shelldyne-H R . On the other hand, the heavier materials, such as TH-MCPD dimer, decalin and tetralin, do not have as great an effect on reducing the heating value of Shelldyne-H R , but larger quantities of these hydrcarbons are required to lower the viscosity of Shelldyne-H R .


In order to evaluate the effect of the various diluents, the -65°F data for each blend from Figures 12 through 18 are combined in Figure 19. The most effective blends tested, with regard to lowering viscosity at 65°F while retaining the highest volumetric energy, were those where toluene was the diluent.

Figure 20 is a plot similar to Figure 19, but only for -40°F viscosity data on the test blends. The relationship between the various test blends


AFAPL-TR-76-17







AFAPL-TR-76-17



Volumetric Heat of Combustion, Btu/Gal X 1000

FIGURE 15. Viscosity at Various Temperatures vs. Volumetric Heat of Combustion for Shelldyne-H/Tetralin




FIGURE 16. Viscosity at Various Temperatures vs. Volumetric Heat of Combustion for Shelldyne-H/t-Decalin




FIGURE 17. Viscosity at Various Temperatures vs. Volumetric Heat of Combustion for Shelldyne-H/Th-MCPD Dimer Blends





FIGURE 18. Viscosity at Various Temperatures vs. Volumetric Heat of Combustion for Shelldyne-H/[sobuty]benzene Blends.



40





FIGURE 20. Viscosity at -40°F for Various Diluent/Shelldyne-H® Blends and Their Effect on the Volumetric Heat of Combustion



is similar to what it was at -65°F. Based on the low temperature, high volumetric energy criteria, toluene blends are best, with the TH-MCPD dimer being the poorest of the diluents tested; the remainder of the diluents fall in between these extremes with regard to these criteria.

As stated previously, Shelldyne-H[®] has the most desirable density and volumetric heating value of any hydrocarbons which will remain a liquid down to -65°F. However, these characteristics are overshadowed by the high viscosity of the materials at sub-zero conditions. The reference batch of Shelldyne-H® (Lot #11410-103) used in this program had viscosities at -65°F of 31,457 centipoise and at -40°F of 3092 centipoise. These values represent problems to the designer of a missile fuel system and engine. If 500 to 1000 centipoise fluids are feasible in a system, the test blends offer attractive options to the designer. Using the test data acquired in this program and the heats of combustion calculated in Appendix F, these data tabulated in Tables VIII, IX, X and XI were developed. These tables list the blends which would have viscosities of 500 or 1000 centipoise at -65°F and -40°F and also the approximate heat of combustion of each blend. In order to compare these blends with Shelldyne-H® and JP-4, the percentages of the volumetric heats of combustion of the blends with regard to these fuels are also indicated.

In Table VIII, all the blends produce 25% more energy than JP-4 and come within 93% of the energy of pure Shelldyne-H $^{\textcircled{@}}$; this effect is significant since the viscosity at -65 $^{\textcircled{O}}$ F is reduced by a factor of 31. The 18% toluene-82% Shelldyne-H $^{\textcircled{@}}$ blends has approximately 97.2% of the volumetric

energy of pure Shelldyne-H® and 130.2% more energy than the JP-4 reference material. Table IX lists the blends that have a viscosity of 500 centipoise at -65°F, together with the approximated heats of combustion and their relation to the reference fuels. Here again, the blends have energies within 8% of Shelldyne-H® and at least 23% more than JP-4. Tables X and XI further exploit the potential available from the fuel blends if the lower temperature limit for specifying fuels is raised. In these tables the viscosity limits of 1000 and 500 centipoise are evaluated at -40°F. Again the toluene blends are most effective; but the other blends with the exception of the TH-MCPD blends are within a percent or two of the energy level of Shelldyne-H®.

Other properties should be considered by the designer in making a selection as to which test blends best suits his application. One such factor is volatility. For high altitude air launched applications, a volatile fuel might be required; therefore, blends of toluene, MCH, and JP-4 would be preferred. For shipboard and submarine applications, where 140°F falshpoint fuels are required, the blends of isobutylbenzene, trans-decalin, tetralin and TH-methylcyclopentadiene dimer are most attractive. Other characteristic fuel properties such as stability, compatibility, combustibility and toxicity probably do not vary with these blends; therefore, they wuld not influence which blend a designer might select.

TABLE VIII

The Heat of Combustion (Vol.) of Various Diluent Shelldyne-H $^{\circledR}$ Blends which have Viscosities of 1000 Centipoise at -65°F.

Diluent	Vol. % (60°F)	ΔH _C Btu/Gal	ΔH _c % Shelldyne-H ®	ΔH _c % of JP-4
Toluene	18	154,000	97.2	130.2
MCH	19.5	153,550	96.9	129.8
JP-4	20	153,100	96.6	129.4
IBB	24.8	152,100	96.0	128.6
t-Decalin	30.5	152,050	95.9	128.5
Tetralin	35.5	153,000	96.5	129.3
TH-MCPD Dimer	60.5	148,300	93.6	125.3

TABLE IX

The Heat of Combustion (Vol.) of Various Diluent Shelldyne-H® Blends which have Viscosities of 500 Centipoise at -65°F.

Diluent	Vol. % (60°F)	ΔH _C Btu/Gal %	ΔH _c Shelldyne-H	ΔH _c % of JP-4
Toluene	24.3	151,900	95.8	128.4
мсн	25.5	151,550	95.6	128.1
JP-4	26.3	150,900	95.2	127.5
IBB	32.5	149,800	94.5	126.6
t-Decalin	39.5	149,900	94.6	126.7
Tetralin	47.2	151,000	95.3	127.6
TH-MCPD	73.5	146,000	92.1	123.4

TABLE X

The Heat of Combustion (Vol) of Various Diluent Shelldyne-H $^{\textcircled{R}}$ Blends which have Viscosities of 100 Centipoise at -40°F.

Diluent	Vol. % (60°F)	ΔH _C Btu/Gal	ΔH _c % Shelldyne-H	ΔH _c % of JP-4
Toluene	6.5	157,800	99.4	133.4
MCH	8.0	157,200	99.2	132.9
JP-4	9.3	156,800	98.9	132.5
IBB	8.8	156,900	99.0	132.6
t-Decalin	12.0	156,500	98.7	132.3
Tetralin	11.0	157,250	99.2	132 9
TH-MCPD Dimer	35.0	152,900	96.5	129.2

TABLE XI

The Heat of Combustion (Vol) of Various Diluent Shelldyne-H $^{\circledR}$ Blends which have Viscosities of 500 Centipoise at -40°F.

Diluent	Vol. % (60°F)	ΔH _C Btu/Gal	ΔH _C % Shelldyne-H®	ΔH _c % of JP-4
Toluene	10.7	156,400	98.7	132.2
мсн	13.0	155,450	98.1	131.4
JP-4	13.8	155,200	97.9	131.2
IBB	14.8	155,100	97.9	131.1
t-Decalin	20.0	154,550	97.5	130.6
Tetralin	20.5	155,550	98.1	131.5
TH-MCPD Dimer	38.5	152,300	96.1	128.7

SECTION VII CONCLUSIONS

It is evident that a serious option for modifying RJ-5 is through blending with thinner (and less dense) hydrocarbons. There are many available materials which can significantly reduce viscosity without causing enormous energy reductions. These materials have, for the most part, differing physical and chemical characteristics which might make one more attractive than others for a particular system. Such characteristics as volatility and saturation are affected by blending and will ultimately aid in choosing the desired blend.

The major conclusion that can be drawn from this effort is that considerable progress is possible in the high density missile fuel area through the blending of hydrocarbon components. Present high density fuels (i.e., RJ-4, RJ-5) can be tailored to yield properties which are more adaptable to system design and yet have significantly more volumetric energy than conventional fuels (i.e., JP-4, JP-5, Jet A. Jet A-1, etc.). Blending should be an acceptable method for "customizing" a fuel since conventional fuels are normally blends of hundreds of different hydrocarbons which, individually, have properties quite different from the blend, but in mixture produce an optimized fuel.

A specific conclusion from this effort is that, on a basis of its improved low temperature viscosity coupled with resulting volumetric heating values, toluene is the best diluent for Shelldyne-H®. However, when considering other characteristics such as volatility, other materials such as methylcyclo-

hexane, tetralin, isobutylbenzene, decalin and even JP-4, might be more desirable. TH-MCPD dimer (RJ-4) is not considered a good blending component with Shelldyne-H® because it does not give much relief in viscosity and its viscosity-heat of combustion relationship is not as good as the other materials tested.

During the past several years, AFAPL has been cooperating with the Air Launched Cruise Missile (ALCM) System Program Office (SPO) in developing a high energy fuel (3,30). This fuel currently is a tertiary blend of Shelldyne-H $^{\textcircled{R}}$, methylcyclohexane, and TH-MCPD; a final specification (JP-9) will be issued shortly. This specification is a result of the blending program at this laboratory.

SECTION VIII RECOMMENDATIONS

The results of this program should be very encouraging to engineers interested in obtaining more range in volume limited systems. Present fuel specifications such as RJ-4 and RJ-5 have deficiencies which can be altered appreciably by blending with other hydrocarbons. The system designer should be aware of the possible fuel options available to him and the fact the Air Force and Navy have fuel development capabilities which could aid in modifying and establishing new fuel specifications for new and unique systems. The cooperative effort, cited previously between ALCM and AFAPL which led to the JP-9 class of fuels is an example of a fuel tailored for a particular system through close coordination and cooperation between fuel systems, engine and fuel development engineers (3, 30). This type of cooperation is recommended in any effort where conventional fuels do not quite achieve performance goals and where compromises are not permitted.

APPENDIX A

CALCULATIONS FOR DETERMINING VISCOSITY ON THE CONE AND

PLATE VISCOMETER

Consider the cone and plate configuration as used on the Weissenberg Rheogoniometer as diagrammed in Figure A-1.

Where,

 α = Angle of cone (degrees)

 β = Angular rotation of the platen (radians/sec)

d = Diameter of the platens (cm)

The rate of shear at any point on the plate or cone is given by:

$$\sigma$$
 = (Angular velocity in radians/sec)/tan α (A-1)

For small cone angles, (A-1) becomes:

$$\sigma = \frac{180}{\pi} (\beta/\alpha) (\sec^{-1})$$
 (A-2)

(A-2) can be rearranged to give the following:

$$\sigma = \frac{360}{\alpha t} (sec^{-1}) \tag{A-3}$$

where
$$t = \frac{2\pi}{\beta}$$
 (sec/rev) (A-4)

The value of t can be determined from the reciprocal of the set speed on the lower platen.




FIGURE A-1. Cone and Plate Viscometer Schematic

Next, the torque measured on the top platen of radius R (cm) is given by:

$$T = \int_0^R 2\pi \, \mu_\alpha \, \sigma r^2 \, dr \qquad (A-5)$$

where

 μ_{α} = Apparent viscosity

r = Distance from center of platen to any point on the platen, cm

(A-5) can be integrated over the entire radius of the platen (R) to give the following:

$$T = \frac{2}{3} \pi \mu_{\alpha} \sigma R^{3} \text{ (dyne-cm)}$$
 (A-6)

 μ_{α} , the apparent viscosity or viscosity coefficient, is expressed in many different dimensions. For our work, the poise or centipoise is most often used. One poise is equal to a dyne-second per cm². Since the work described in this report deals only with Newtonian fluids, the apparent viscosity (μ_{α}) is the viscosity of the material and is constant for all shear rates and shear stresses. Therefore, we will use:

$$\mu = \mu_{\alpha} \tag{A-7}$$

Incorporating (A-7) into (A-6) and rearranging, one will obtain:

$$\mu = (3/2) (T) / (\pi \sigma R^3) (poise)$$
 (A-8)

Incorporating (A-3) into (A-8) one obtains

$$\mu (3\alpha tT)/(720 \pi R^3)$$
 (A-9

or
$$\mu = (\alpha t T)/(30 \pi d^3)$$
 (A-10)

where d = 2R

or $R^3 = (\frac{1}{8})d^3$

(A-10) can be further simplified to:

$$\mu = \frac{\alpha tT}{94.25} d3 \tag{A-11}$$

In the Weissenberg Rheogoniometer, the torque on the upper platen can be related to the movement of the upper platen and a constant which relates displacement to torque:

$$T = \Delta m K_{T}$$
 (A-12)

where Δm = Movement of torsion head transducer, microns

 K_T = Calculated torsion bar constant, dyne-cm/micron

The torsion bar used in our program was the lightest available and was calibrated to have a constant of 1.851×10^1 dyne-cm of torque per micron of displacement. Therefore, for our program, the torque on the upper platen was given as:

$$T = 18.51 \Delta m \text{ (dyne-cm)} \tag{A-13}$$

For the test program, only the 5 cm (diameter) platens were used with the 2° 0'22" cone angle. Therefore, by substituting (A-13) in (A-11) and incorporating the values for the α and d^3 one obtains the following expression for viscosity:

$$\mu = 3.1519 \times 10^{-3} \text{ (t } \Delta \text{m)}$$
 (A-14)

The period, t (time required for the revolution of the bottom platen), is readily obtained from the gearbox settings which offers 60 easily selected output speeds in equal ratio steps of $10^{-0.1}$ (1:1.259 reduction). The manufacturer supplies a table of rotation speeds (RPM) and t (sec/rev) for the 60 possible gear box settings. In our work, we used only the settings which corresponded to 167.0, 16.7 and 1.67 sec/revolution. Since the fluids were all Newtonian, their viscosities were independent of shear rate and platen speeds were selected to give acceptable readings on the 0 to 200 micron range. It was felt that this range was the optimum from an accuracy viewpoint.

Other calculations of interest in this effort were those for determining shear stress and shear rate. It is well known that for Newtonian fluids, the shear stress is directly proportional to the shear rate. The proportionality constant is commonly called the viscosity coefficient or merely the viscosity:

$$S = \mu \sigma$$

where $S = \text{shear stress } (\frac{\text{dyne}}{\text{cm}^2})$ (A15)

For the calculations involved in our research, (A-15) can be rearranged using (A-14) and (A-3) to obtain

$$S = 0.5657 \ \Delta m \ (dyne/cm^2)$$
 (A16)

Equation (A-16) is only applicable for the 5 cm diameter platen using the 6/26 torsion bar and is independent of α . Other size platens and torsion bars will require modification of the constant.

The shear rate can be determined from (A-3) for the 2° 0'22" cone angle of our specimen:

$$\sigma = (179.4517)/t (sec^{-1})$$
 (A-17)

The constant in this expression will change with different cone angles, α :

In summary, the calculations required in this effort where the 5 cm diameter platens, $2^{\circ}0'22''$ cone angle and 6/26 (identifying number, K_{T} = 18.51 dyne-cm) torsion bar were used as follows:

Viscosity (from A-14)
$$\mu = 3.1519 \times 10^{-3}$$
 (t Δm) (poise)
Shear rate (from A-17) $\sigma = (179.4517)/t$ (sec⁻¹)
Shear stress (from A-16) $S = 0.5657 \Delta m$ (^{dynes/cm²})

APPENDIX B

THERMAL EXPANSION OF THE WEISSENBERG RHEOGONIOMETER

From Appendix A it was noted that the cone on the bottom platen was truncated (Figure A-1). It is vital for the sake of accuracy that the point of the cone should just touch the center of the flat platen. This, however, would disturb the reading of the torque so the point of the cone is truncated to prevent this interference. This gives negligible error (26); the torque produced at the center of the platen being immeasurable, but it is vitally important to adjust the gap between the truncated cone of the bottom platen and the flat surface of the top platen as accurately as possible. The imaginary top of the cone should touch the center of the upper platen. The amount of truncation for the Platen Nr 1141 (2° 0' 22") used in this program was 91 microns; this was determined by the manufacturer and engraved on the back of the cone.

Since this program involved making measurements at temperatures other than ambient, it was necessary to determine the effect of temperature change on the test equipment and the gap between the platens. The instruction manual (26) reported that the gap between platens would close up by about 0.69 microns for each °F that the platens are heated. The exact change, of course, would differ depending on the size of the torsion bar platen holder and test platens. Therefore, a program was formulated to determine the amount of adjustment necessary to keep the gap setting constant at each temperature tested. Since we used only the Nr 1141 platen, we needed to maintain the gap setting at 91 microns.

A unique feature of the R-17 Weissenberg Rheogoniometer is the micrometer gap setting knob that is provided. The exact procedure for gap setting is outlined in Reference 26. Since our testing would include measurements to -75°F, we had to determine the adjustment necessary to assure the correct gap setting. A description of the procedure used follows. The 5 cm platens (Nr 1141 and Nr 865) were put onto the instrument. The alignment procedures were followed and the gap was set at 91 microns at 75°F. Using the normal cooling technique of cold nitrogen gas, the temperature of the test chamber was lowered 150°F to -75°F, and the test platens were emptied. By using the gap setting knob micrometer dial, the gap setting at this lower temperature could be determined. The chamber was cold soaked for one hour and the gap was found to have expanded to 221 microns. The gap was reset at 221 microns at -75°F and the temperature was raised to -50°F where the gap setting had decreased to 198 microns. This gap was reset and the temperature was raised to -25°F where the gap was checked. This procedure was followed at each temperature until ambient was reached. The summary of the temperature effect on gap setting is as follows in Table B-1.

A plot of gap setting adjustment as a function of temperature is shown in Figure B-1. This plot was used to determine the appropriate adjustment in gap setting for each test temperature in this program. From our experimentation it was found that the gap closed an average of approximately 0.867 microns per °F which agrees rather closely with the manual's estimate of 0.69 microns/°F.




FIGURE B-1. Gap Setting Adjustment at Various Temperatures

TABLE B-1

SUMMARY OF THE EFFECT OF TEMPERATURE ON GAP SETTING

Platens: Flat, Nr 865, 5 cm diameter
Cone, Nr 1141, 5 cm diameter
2° 0' 22" cone angle
Apex of Cone - 91 microns

Torsion Bar: Nr 6/26 $K_T = 18.51$ dyne-cm/micron

Gap Setting, Microns	Difference, Microns
91	0
221	130
198	107
180	89
163	72
143	52
91	0
	91 221 198 180 163 143

The following procedure was outlined and followed in making viscosity measurements below room temperature:

- (1) The gap is set at ambient room temperature (between 65°F and 75°F). The upper platen is raised at least 5 cm.
- (2) A slight excess of sample to be evaluated is placed on the lower platen. From the instruction manual (26), the sample size can be determined.

Sample Size =
$$\frac{d^3 \alpha}{218}$$
 (B-1)

For our platens this size is approximately 1.15 cubic centimeters. We will load approximately 2.00 cubic centimeters of test fluid.

- (3) The upper platen is lowered, but only until the top surface of the sample is contacted.
- (4) Using the cold nitrogen gas system, the chamber temperature is lowered to the lowest test temperature. The upper platen is then lowered until it comes to the correct stop.
- (5) After 15 minutes at this test temperature, the gap is adjusted as indicated by the chart on Figure B-1 or by calculations, the reduction necessary from the fact that the gap will open by 0.867 microns per °F.
- (6) After an additional 15 minutes, determine the viscosity at the shear rate of interest. The procedure for determining viscosities is outlined in Appendix C and should be followed for each determination at each temperature of interest.
- (7) After another 15 minute interval, Step (6) is repeated. The results are compared and if the results are within 1 meter indication, continue on to Step (8). If the results are not within 1 meter indication, Step (7) is repeated until two consecutive readings are within 1 meter indication.
- (8) Proceed to the next highest temperature; repeat Steps (5) through(7).
- (9) Continue running until viscosities are determined at the required shear rates and temperatures.

The test temperatures in this program were -65, -50, -40, -25, 0, 25, 50 and $70^{\circ}F$.

APPENDIX C

VISCOSITY DETERMINATION PROCEDURES FOR THE R17 WEISSENBERG RHEOGONIOMETER

Following is the procedure for obtaining viscosity determination on the Model R17 Weissenberg Rheogoniometer.

- (1) The operator should be familiar with the "Weissenberg Rheogoniometer Model R17 Instruction Manual" which is obtainable from Sangamo Controls, Ltd. through Technidyne Corporation, Louisville, Kentucky.
- (2) The transducer meters and servo system amplifiers should be switched on 15 minutes or more before testing is to be carried out to allow them to reach their operating temperature and stablize.
- (3) Each transducer meter is calibrated before starting the test series.

 The range is put on "CAL" and the "SET CALIBRATION" adjustment altered so that the transducer meter needle is exactly on the full scale mark.
- (4) The appropriate plates and torsion bars are fitted as outlined in the instruction manual.
- (5) The required gearbox speed is selected, using the setting as determined from Table C-1.
- (6) The gap is set as outlined in detail in the manual. Ambient room temperature should be in the range of 65°F-75°F.
- (7) The upper platen is raised at least 5 cm and the sample is loaded.

 The procedures outlined in Appendix B, with reduced test temperatures, should be followed at this point.
- NOTE: During the test the least sensitive range of the transducer meters should be chosen to start with and the more sensitive ranges selected, as necessary, to prevent possible damage to the equipment.

- (8) At each determination, the transducer meters and recorders should be set at the correct range.
- (9) The rotation motor should be started and the brake/drive unit should be switched to "DRIVE".
- (10) The operator should record the following information in his record book: the date, time, test specimen, gap setting, temperature, gap setting adjustment, transmission setting.
- (11) The readings on the transducer meter should be noted and recorded in the record book.
 - (12) The test is completed and the brake/drive unit is switched to "BRAKE".
- (13) If the test is to be repeated, Steps (9) through (12) are repeated. When changing test temperatures, the procedures in Appendix B should be consulted.

TABLE C-1

ROTATIONAL SPEEDS - 3600 R.P.M. MOTOR

NTION	SEC/CYCLE	1.67 × 10 ⁻² 2.10 × 10 ⁻² 2.63 × 10 ⁻² 3.31 × 10 ⁻² 4.17 × 10 ⁻²	5.27 x 10 ⁻² 6.61 x 10 ⁻² 8.33 x 10 ⁻² 10.50 x 10 ⁻² 13.19 x 10 ⁻²	
OSCILLATION	C.P.S.	6.00 × 10 4.76 × 10 3.80 × 10 3.02 × 10 2.40 × 10	18.96 15.12 12.00 9.52 7.58	
NOIL	SEC/REV	0.84 × 10 ⁻¹ 1.05 × 10 ⁻¹ 1.32 × 10 ⁻¹ 1.67 × 10 ⁻¹ 2.09 × 10 ⁻¹	2.64 x 10 ⁻¹ 3.32 x 10 ⁻¹ 4.17 x 10 ⁻¹ .53	
ROTATION	R.P.M	7.20 × 10 ² 5.72 × 10 ² 4.54 × 10 ² 3.60 × 10 ² 2.88 × 10 ²	2.28 x 10 ² 1.808 x 10 ² 1.438 x 10 ² 1.142 x 10 ² 9.08 x 10 ¹	
GEARBOX SETTING	LEFT	0.0	0.0000	
GEARBOX	RIGHT	0	· 0	

street 11 (8)

TABLE C-1

ROTATIONAL SPEEDS - 3600 R.P.M. MOTOR

ATION	SEC/CYCLE	1.67 × 10 ⁻¹	2.63 X 10 ⁻¹	3.31 × 10-1	4.17 × 10 ⁻¹	5.27 x 10 ⁻¹	6.61 x 10 ⁻¹	8.33 x 10 ⁻¹	10.50 x 10 ⁻	13.19 x 10 ⁻		
OSCILLATION	C.P.S.	6.00	3.80	3.02	2.40	1.896	1.512	1.200	0.952	0.758		
TION	SEC/REV	0.83	1.32	1.67	2.09	2.64	3.32	4.17	5.25	09.9	STREET - SPECIAL BUNCHESTS	
ROTATION	R.P.M	7.20 X 10	4.54 × 10	3.60 x 10	2.88 x 10	2.28 X 10	1.808 x 10	1.438 x 10	1.142 X 10	9.08	THE STREET STREET	
(SETTING	LEFT	0.0	0.2	0.3	4.0	0.0	0.1	0.2	0.3	4.0		
GEARBOX SETT	RIGHT	1.0				1.5						

TABLE C-1

R.P.M. MOTOR

ROTATIONAL SPEEDS - 3600

SEC/CYCLE 5.27 6.61 8.33 10.50 1.67 2.10 2.63 3.31 4.17 OSCILLATION 1.896 x 10⁻¹ 1.512 x 10⁻¹ 1.200 x 10⁻¹ 0.952 x 10⁻¹ 0.758 x 10⁻¹ C. P. S. 0.600 0.476 0.380 0.302 0.240 SEC/REV 22222 ××××× 8.3 10.5 13.2 16.7 20.9 2.64 3.32 4.17 5.25 6.60 ROTATION R.P.M 2.28 1.808 1.438 1.142 0.908 7.20 5.72 4.54 3.60 2.88 0.00.7 0.0 LEFT GEARBOX SETTING RIGHT 2.0 2.5

TABLE C-1

ROTATIONAL SPEEDS - 3600 R.P.M. MOTOR

3.0 0.0 7.20 × 10 ⁻¹ 8.3 × 10 0.1 5.72 × 10 ⁻¹ 10.5 × 10 0.2 4.54 × 10 ⁻¹ 13.2 × 10 0.3 3.60 × 10 ⁻¹ 16.7 × 10 0.4 2.88 × 10 ⁻¹ 2.64 × 10 ² 0.1 1.808 × 10 ⁻¹ 3.32 × 10 ² 0.2 1.438 × 10 ⁻¹ 3.32 × 10 ² 0.3 1.142 × 10 ⁻¹ 5.25 × 10 ² 0.4 0.908 × 10 ⁻¹ 6.60 × 10 ²	ROTATION	OSCILLATION
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	SEC/REV C.P.S.	S. SEC/CYCLE
0.0 0.1 5.72 × 10 ⁻¹ 0.2 4.54 × 10 ⁻¹ 0.3 3.60 × 10 ⁻¹ 0.4 2.28 × 10 ⁻¹ 1.808 × 10 ⁻¹ 0.0 1.438 × 10 ⁻¹ 2.64 × 0.1 1.42 × 10 ⁻¹ 2.0.9 × 11 2.64 × 0.9 0.9 0.9 0.9 0.9 0.9 0.9 0.9		
0.0	8.3 × 10	× 10-1 1.67 × 10-1
0.0 0.1 0.0 0.0 0.0 0.0 0.0 0.0		
0.0 2.28 × 10 ⁻¹ 2.64 × 0.1 4.38 × 10 ⁻¹ 3.32 × 0.3 1.142 × 10 ⁻¹ 5.25 × 0.4 0.908 × 10 ⁻¹ 6.60 ×		
0.0 0.1 1.808 × 10 ⁻¹ 0.2 1.438 × 10 ⁻¹ 1.42 × 10 ⁻¹ 0.3 1.142 × 10 ⁻¹ 5.25 × 0.4 0.908 × 10 ⁻¹ 6.60 ×		
0.0 2.28 × 10 ⁻¹ 3.64 × 0.1 1.808 × 10 ⁻¹ 3.32 × 0.2 1.438 × 10 ⁻¹ 4.17 × 0.3 1.142 × 10 ⁻¹ 5.25 × 0.4 0.908 × 10 ⁻¹ 6.60 ×		
0.0 2.28 × 10 ⁻¹ 3.32 × 0.1 1.808 × 10 ⁻¹ 3.32 × 0.2 1.438 × 10 ⁻¹ 4.17 × 0.3 1.142 × 10 ⁻¹ 5.25 × 0.4 0.908 × 10 ⁻¹ 6.60 ×		
0.1 1.808 × 10 ⁻¹ 3.32 × 0.2 1.438 × 10 ⁻¹ 4.17 × 0.3 1.142 × 10 ⁻¹ 5.25 × 0.4 0.908 × 10 ⁻¹ 6.60 ×	05	1.896×10^{-2} 5.27 × 10,
1.438 × 10 ⁻¹ 4.17 × 1.142 × 10 ⁻¹ 5.25 × 0.908 × 10 ⁻¹ 6.60 ×	02	× 10_2 6.61 × 101
1.142 × 10 ⁻¹ 5.25 × 0.908 × 10 ⁻¹ 6.60 ×	0,50	8.33 ×
× 09.9	0,50	10.50 ×
	0,	13.19 ×

TABLE C-1

ROTATIONAL SPEEDS - 3600 R.P.M. MOTOR

OSCILLATION	S. SEC/CYCLE	x 10-2 1.67 x	x 10 ⁻² 2.10 x	x 10 ⁻² 3.31 x 10 ⁻² 4.17	10-3	x 10-3 x 10-3 x 10-3 x 10-3	x 10-3 10.50 x	x 10-5 13.19 x	
0.023 0.023 0.023	C.P.S.	0.600)	0.476)	0.302)	7 806	1.512	0.952)	0.758)	
TION	SEC/REV	8.3 x 10 ² ,	10.5 × 102 13.2 × 102	16.7 × 10 ² 20.9 × 10 ²	>	3.32 × 103 1.17 × 103	×	×	
ROTATION	R.P.M	7.20 × 10 ⁻²	5.72 × 10 ⁻² 4.54 × 10 ⁻²	3.60 × 10 ⁻² 2.88 × 10 ⁻²	2 28 × 10-2	1.808 × 10 ⁻²	1.142 × 10-2	0.908 X 10-2	
GEARBOX SETTING	LEFT	0.0	0.1	0.3		0.00	0.3	6.4	
GEARBO	RIGHT	4.0			4 5	?			

TABLE C-1 ROTATIONAL SPEEDS - 3600 R.P.M. MOTOR

TION	SEC/CYCLE	1.67 × 103 2.10 × 103 2.63 × 103 3.31 × 103 4.17 × 103	5.27 x 103 6.61 x 103 8.33 x 103 10.50 x 103 13.19 x 103
OSCILLATION	C.P.S.	0.600 x 10 ⁻³ 0.476 x 10 ⁻³ 0.380 x 10 ⁻³ 0.302 x 10 ⁻³ 0.240 x 10 ⁻³	1.896 × 10-4 1.512 × 10-4 1.200 × 10-4 0.952 × 10-4 0.758 × 10-4
LION	SEC/REV	8.3 x 10 ³ 10.5 x 10 ³ 13.2 x 10 ³ 16.7 x 10 ³ 20.9 x 10 ³	2.64 × 104 3.32 × 104 4.17 × 104 5.25 × 104 6.60 × 104
ROTATION	К.Р.М	7.20 × 10 ⁻³ 5.72 × 10 ⁻³ 4.54 × 10 ⁻³ 3.60 × 10 ⁻³ 2.88 × 10 ⁻³	2.28 x 10 ⁻³ 1.808 x 10 ⁻³ 1.438 x 10 ⁻³ 1.142 x 10 ⁻³ 0.908 x 10 ⁻³
GEARBOX SETTING	LEFT	0.0 0.1 0.3 0.4	0.0 0.1 0.3 0.3
GEARBO)	RIGHT	5.0	5.5

APPENDIX D

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA SHEETS

The viscosity data were generated using the procedures outlined in Appendices B and C and the calculation presented in Appendix A. Table D-1 lists the sample number of each fluid tested in this program and identifies its chemical composition on a volume percentage basis.

Table D-2 is the data which was taken on the rheogoniometer and converted into viscosities and shear rates. Each data point in Table D-2 usually represents the average of two determinations. In addition, the project record book and associated page number where these data are recorded is also noted in this table. As an example "RB Nr 55422 (21 and 23)" would indicate that these data can be found in Record Book 55422 on pages 21 and 23.

TABLE D-1

COMPOSITION OF FUEL BLENDS EVALUATED ON WEISSENBERG RHEOGONIOMETER

SAMPLE NUMBER	CHEMICAL COMPOSITION, VOL. %
SH	Shelldyne-HO(SH), Batch Nr LR-11410-103
SH A	Shelldyne-Hound unknown Batch number
SH B	Shelldyne-HD Batch Nr LR-10318-174, Barrel #2
SH C	Shelldyne-HD Batch Nr LR-10318-174, Barrel #1
SH D	Shelldyne-H, Batch Nr LR-10704-45
SH-1	94.9% SH, 5.1% toluene
SH-2	87.7% SH, 12.3% toluene
SH-3	70.9% SH, 29.1% toluene
SH-4	64.9% SH, 35.1% toluene
SH-5 & SH-5A	46.3% SH, 53.7% toluene
SH-6	93.1% SH, 6.9% JP-4
SH-7	86.5% SH, 13.5% JP-4
SH-8 & SH-8A	68.1% SH, 31.9% JP-4
SH-9	56.9% SH, 43.1% JP-4
SH-10	41.6% SH, 68.4% JP-4
SH-11	93.1% SH, 6.9% methylcyclohexane (MCH)
SH-12	86.5% SH, 13.5% MCH
SH-13	68.1% SH, 31.9% MCH
SH-14	56.9% SH, 43.1% MCH
SH-15	41.6% SH, 58.4% MCH
SH-16	94.5% SH, 5.5% tetralin
SH-17	89.1% SH, 10.9% tetralin
SH-18	73.2% SH, 26.8% tetralin
SH-19	62.9% SH, 37.1 tetralin
SH-20	47.7% SH, 52.3% tetralin
SH-22A	45.2% SH, 54.8% cis-decalin
SH-26A	45.2% SH, 54.8% trans-decalin
SH-28A	100% TH-methylcyclopentadiene dimer (TH-MCPD)
SH-29A	94.3% SH, 5.7% TH-MCPD
SH-30A	88.5% SH, 11.5% TH-MCPD
SH-31A	72.2% SH, 27.8% TH-MCPD
SH-32A	61.7% SH, 38.3% TH-MCPD
SH-33A	46.3% SH, 53.7% TH-MCPD
SH-34	94.1% SH, 5.9% trans-decalin
SH-35	88.1% SH, 11.9% trans-decalin
SH-36	71.0% SH, 29.0% trans-decalin
SH-37	60.3% SH, 39.7% trans-decalin
SH-38	45.2% SH, 54.8% mixed decalin isomers
SH-39	93.8% SH, 6.2% isobutylbenzene (IBB)
SH-40	87.7% SH, 12.3% IBB
SH-41	70.4% SH, 29.6% IBB
SH-42	59.7% SH, 40.3% IBB
SH-43	44.2% SH, 55.8% IBB

AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

PLATEN DATA:	Diame	rer I	5.0 cm	Cone	Cone Angle	2° 0' 22"	Gap	Gap Setting 91 Micro	Microns nd 23)
	Trops Trops strud fr	110707	Torsion Bar Data:	,	= 1.851	K _T = 1.851 X 10' Dyne-cm/Micron		•	
	Test Temperatures	tures	Gap Setting	Transı	Transmission		7	p 20040	4 1 2000 IV
Number	Millivolts	<u>ь</u>	Microns	Left	Right	Sec/P.ev	(Meter Reading)	Sec-1	Centipoise
SH-1	-1.93	-65.2	-123	0.3	3.0	167.0	85.3	1.075	4,489.9
SH-1	-1.47	40.4	-102	0.3	0.00	167.0	16.0	1.075	842.2
SH-1	79.0-	0 20	99 -		2.0	16.7	22.0	10.746	342.1
SH-1	0.40	50.3	- 22	200	0.01	1.67	48.0	107.456	25.3
				.;	2.	70:-	0.4.0	10/.456	17.9
SH-4	-1.93	-65.2	-123	0.3	2.0	16.7	21.0	10.746	110.5
SH-4	-1.47	+40.4	-102	0.0	0.0	1.67	76.0	107.456	40.0
SH-4	-0.67	0	999 -	0.3	0	1.67	26.0	107.456	13.7
SH-4	0.40	25.3	- 44	0.0	0.0	1.67	0.61	107.456	10.0
5H-4	0.84	70.3	17 -	0.3	0.0	1.67	13.0	107.456	4.9
			10 10 10 10 10 10 10 10 10 10 10 10 10 1				AZ-		

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

91 Microns	55422 (20 and 22)			Sec-1 Centipoise	1.947.5					746 289.5				
Gap Setting	RB # 55422		-	-	1.075	10.746	10.746	107.456	107.456	10.7	10.746	107.	107.456	
		Dyne-cm/Micron		(Meter Reading)	37.0	72.5	13.38	65.0	26.5	26.3	10.25	30.0	19.8	
2° 0' 22"	1141	× 10-		Sec/Rev	167	16.7	16.7	1.67	1.67	16.7	16.7	1.67	1.67	
Cone Angle	Cone Nr	T = 1.851	Transmission	Right	3.0	2.0	2.0	0.0	0.	2.0	2.0	0.0.	0.0.	
CO	Co.	Data: K _T	Tran	Left	0.3	0.3	0.3	0.0	0.0	0.00	200	0.0	0.0	
5.0 cm	52	Torsion Bar Data:	Gap Setting	Microns	-123	-102	99 -	- 44	4 -	-123	- 88	99 -	- 22	
Diameter 5.	Nr 865		Temperatures	р. 0	-65.2	-40.4	0	25.3	70.3	-65.2	-25.2	25.3	50.3	
	Flat	2 (Cont'd)	Test Temper	Millivolts	-1.93	-1.47	-0.67	-0.14	0.84	-1.93	1.1.	-0.14	0.40	
PLATEN DATA:		TABLE 0-2		Number	SH-2 SH-2	SH-2	SH-2	SH-2	SH-2	SH-3	SH-3	SH-3	SH-3 SH-3	

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

=				
Microns	μ V 1 5 5 5 5 1 + V	Centipoise	73.7 74.2 74.2 74.2 19.5 19.5 6.3 7.658.6	2.184.4 1.131.7 447.4 447.4 450.0 147.4 61.8 30.0
Gap Setting 91 Micr RB # 55422 (24 and 25)	p 1	Sec-1	10.746 107.456 107.456 107.456 107.456 107.456 107.456 107.456	1.075 1.075 1.075 10.746 10.746 10.746 107.456
Gap RB Dyne-cm/Micron	3	(Meter Reading)	14.0 141.0 76.0 56.3 37.0 21.3 17.0 13.13	41.5 8.5 85.5 28.0 11.75 38.0
1 01		Sec/Rev	16.7 1.67 1.67 1.67 1.67 1.67 1.67	167 167 16.7 16.7 16.7 1.67
Cone Angle 2° 0' Cone Nr 1141 K _T = 1.851 X 10'	Transmission	Right	27	00000000
0 0	Trans	Left		00000000
865 Torsion Bar Data:	Gap Setting	Microns	-123 -123 -110 -102 - 88 - 66 - 44 - 22 - 22 - 123	110 102 103 103 103 103 103 103 103 103 103 103
	tures	ů.	-65.2 -50.1 -40.4 -25.2 -25.3 -65.3	-50.4 -25.2 -25.2 -25.3 70.3
LATEN DATA: Diameter Flat Nr TABLE D-2 (Cont'd)	Test Temperatures	Millivolts	-1.93 -1.65 -1.67 -1.18 -1.93 -1.93	0.47 0.40 0.40 0.40 0.40
PLATEN DATA: TABLE D-2 (Number	**************************************	2

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

ABLE D-	יומר	Flat Nr 86	865	Con	Cone Nr	1141	RB A	# 55422 (26 and 27)	27)
	TABLE D-2 (Cont'd)		Torsion Bar Data:		K _T = 1.851 x 10 ¹		Dyne-cm/Micron		
1	Test Temper	emperatures	Gap Setting	Trans	Transmission			6	4
Sample	Millivolts	4 0	Adjustment	Left	Right	Sec/Rev	(Meter Reading)	Sec-1	Centipoise
SH-7	-1.93	-65.2	-123	0.3	3.0	167	52.5	1.075	2,763.4
SH-7	-1.47	-40.4	-110	0.0	3.0	167	10.25	1.075	539.5
2H-7	-1.18	-25.2	1 80 00	0.3	2.0	16.7	46.5	10.746	244.8
2H-7	-1.47	40.4	-102	0.3	2.0	16.7	102.0	10.746	536.9
1-H-7	-0.67	25.3	77 - 99 -	0.0	2.0	16.7	16.5	10.746	86.9
SH-7 SH-7	0.40	70.3	- 22	000	000	1.67	40.5	107.456	21.3
H-RA	-1 03	24.	-123	0	c	7 31	0 17	27.0	
SH-8A	-1.65	-50.1	110	0.0	2.0	16.7	27.63	10.746	145.4
SH-8A	-1.47	F40.4	-102	0.3	2.0	16.7	18.5	10.746	97.4
SH-8A	-0.67	0	99 -	0.3	1.0	1.67	50.0	107.456	26.3
SH-8A	-0.14	25.3	77 -	0.3	0.1	1.67	31.3	107.456	16.5
SH-8A	0.84	70.3	4 -	0.3	0.0.	1.67	15.5	107.456	8.2

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

													-		
Microns nd 29)		μ γ+1.2002 ! V	Centipoise	157.9	81.0	55.4	34.2	10.7	55.3	23.2	15.3	0.0	6.4	9.50	
RB # 55422 (28 and 29)		p 240	Sec-1	10.746	10.746	107.456	107.456	107.456	10.746	107.456	107.456	107.456	107.456	107.456	
RB ##	Dyne-cm/Micron	2	(Meter Reading)	30.0	15.38	105.0	65.0	20.3	10.5	0.44	29.0	12.68	9.25	· · ·	100000000000000000000000000000000000000
11411	10.		Sec/Rev	16.7	16.7	1.67	1.67	1.67	16.7	1.67	1.67	1.67	1.67	/0:	No see like
I I	= 1.851 X	Transmission	Right	2.0	2.0	2.0	0.0	0.0	2.0	1.0	0.0	1.0	0.1	2	To Market Co
Cone	ta: K _T	Transi	Left	0.3	0.0	0.3	0.3	0.0	0.3	0.3	0.0	0.3	0.3	3	
	Torsion Bar Data:	Gap Setting	Microns	-123	-110	-102	88 9 9	- 44	-123	-102	989	77 -	- 22	r	
Nr 865		tures	L.	-65.2	-50.1	-40.4	-25.2	25.3	-65.2	40.4	-25.2	25.3	50.3	0.00	
Flat	(Cont'd)	Test Temperatures	Millivolts	-1.93	-1.47	-1.47	-1.18	-0.14	-1.93	-1.47	10.18	-0.14	0.40		
	TABLE D-2 (Cont'd		Number	SH-9	6-H2	SH-9	SH-9 SH-9	SH-9 SH-9	SH-10 SH-10	SH-10	SH-10	SH-10	SH-10	2	

AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Microns 55422(30)	Viscosity Centipoise	6,053.1 1,805.4 968.5 407.9 397.4 134.2 57.9	2,237.0 479.0 479.0 227.9 82.9 39.5 15.3
Gap Setting 91 Microns RB # 55422(30)	Shear Rate Sec-1	1.075 1.075 1.075 1.075 1.075 10.746 10.746 10.746	1.075 1.075 10.746 10.746 10.746 107.456 107.456
RB / RB /	Δm, Microns (Meter Reading)	115.0 34.3 18.4 7.75 75.5 25.5 11.0 37.0	42.5 43.3 475.0 75.0 29.0 29.0
" -	t Sec/Rev	167 167 167 16.7 16.7 16.7	167 16.7 16.7 16.7 16.7 16.7 1.67
Cone Angle 2° 0' Cone Nr 114 $K_{T} = 1.851 \times 10'$	Transmission Left Right	000000000000000000000000000000000000000	0000000
	Transı	00000000	0000000
865 Torsion Bar Data:	Gap Setting Adjustment Microns	-123 -110 -1102 - 88 - 88 - 66 - 66 - 22 - 44	-123 -110 -102 - 83 - 66 - 44 - 22 - 22
1 1	tures	-65.2 -50.1 -40.4 -25.2 -25.2 -25.3 70.3	-65.2 -50.1 -25.2 -25.3 70.3
TA: Diameter Flat Nr 2 (Cont'd)	Test Temperatures Millivolts °F	-1.65 -1.65 -1.18 -1.18 -0.67 -0.40	-1.693 -1.1.47 -0.67 -0.44 -0.84
PLATEN DATA: TABLE D-2 (Con	Sample		SH-12 SH-12 SH-12 SH-12 SH-12 SH-12 SH-12

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

		-	-	
Microns 5)		#	Centipoise	321.1 154.2 104.6 59.2 66.3 66.3 13.2 13.2 10.5 4.2.1 22.6 14.7 9.7 7.9
Gap Setting 91 M RB # 55423 (4 and 5)		6	Shear Kate Sec-1	10.746 10.746 10.746 10.7456 107.456 107.456 107.456 10.746 10.746 10.746 10.746 10.746 10.746 10.7456
Gap RB	cm/Micron		Am, Microns (Meter Reading)	61.0 29.3 19.88 11.25 11.25 40.0 25.0 25.0 25.0 26.5 40.0 43.0 43.0 43.0 15.0
2° 0' 22"	K _T = 1.851 X 10' Dyne-cm/Micron	-	Sec/Rev	16.7 16.7 16.7 1.67 1.67 1.67 1.67 1.67
Cone Angle	1.851	Transmission	Right	0000000 0000000000000000000000000000000
Cone		Transı	Left	000000000000000000000000000000000000000
5.0 cm 865	Torsion Bar Data:	Gap Setting	Adjustment	- 123 - 123 - 102 - 88 - 66 - 66 - 66 - 66 - 66 - 74 - 74 - 74 - 74 - 74 - 74 - 74 - 74
-		tures		65.2 25.2 25.2 25.2 25.3 70.3 70.3 70.3
TA: Diameter Flat Nr	(Cont'd)	Test Temperatures	Millivolts	1
PLATEN DATA:	TABLE D-2 (Cont'd)		Sample	SH-13 SH-13 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-14 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-13 SH-14 SH-13 SH-13 SH-13 SH-13 SH-13 SH-14 SH-13 SH-14 SH-14 SH-14 SH-13 SH-14

AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

μ scosity	entipoise	26.3 20.7 14.7 14.7 8.2 4.5 3.0 3.0 159.1 631.7 658.0 71.1 32.9	
Shear Rai	Sec-1	107.456 107.456 107.456 107.456 107.456 107.456 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075	
Δm, Microns	(Meter Reading)	80.0 39.3 39.3 15.5 6.5 6.5 7.4.5 12.5 31.0 13.5 62.5	
t	Sec/Rev	1.67 1.67 1.67 1.67 1.67 1.67 1.67 1.67	
E L		00000000 0000000	
Trans	Left		
Gap Setting Adjustment	Microns	-123 -102 -102 -103 -103 -103 -103 -103 -103 -103 -103	
tures	,	250.2 250.3 25	
1 1 .	Millivolts	1.93 1.65 1.1.47 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65 1.1.65	
Sample	Number	************************************	
	Test Temperatures Gap Setting Transmission t Am, Microns Shear Rate	Temperatures Gap Setting Transmission t Adjustment Adjustment Left Right Sec/Rev (Meter Reading) Sec-l	Test Temperatures Gap Setting Transmission t Adjustment Adjustment Left Right Sec/Rev (Meter Reading) Sec-1 Sec-1 Nicrons Left Right Sec/Rev (Meter Reading) Sec-1 Sec-1 Nicrons Left Right Sec/Rev (Meter Reading) Sec-1 Sec-1 Nicrons Left Right Sec/Rev (Meter Reading) Sec-1 Nicrons Left Sec/Rev (Meter Reading) Sec-1 Nicrons Sec-1 Nicrons Left Sec/Rev (Meter Reading) Sec-1 Nicrons Left Sec/Rev (Meter Reading) Sec-1 Nicrons Sec-1 Nicrons Sec-1 Nicrons Sec-1 Nicrons Rev Left Sec/Rev (Meter Reading) Sec-1 Nicrons Rev Left Sec/R

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

etting 91 Microns 55423 (9 and 10)		Shear Rate Viscosity Sec-1 Centipoise	1.075 7,974.4 1.075 2,158.1 1.075 1,042.2 1.075 4,23.7 10.746 133.2 10.746 133.2 10.746 153.3 10.746 16.8 10.746 16.8 10.746 152.6 10.746 152.6 10.746 152.6 10.746 152.6 10.746 152.6 10.746 152.6 10.746 152.6
Gap Setting RB # 55423	Dyne-cm/Micron	∆m, Microns (Meter Reading)	151.5 41.0 19.8 80.5 25.0 32.5 50.0 32.5 12.63 110.0 110.0 18.0
2° 0' 22"	X 10' Dyne-	sec/Rev	167.0 167.0 167.0 167.0 167.0 16.7 16.7 16.7 16.7 16.7 16.7 16.7
Angle	1.851	Right	
Cone	ata: K _T	Left	
0 cm	Torsion Bar Data:	Adjustment Microns	-123 -123 -123 -123 -123 -123 -123 -123
ster 5.0 Nr 865		° F	65.2 -40.4 -40.4 -50.3 -40.4 -60.3 -70
Diame	TABLE D-2 (Cont'd)		
PLATEN DATA:	TABLE D-	Sample	**************************************

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Torsion Bar Data: K _T = 1.851 × 10¹ Dyne-cm/Micron Gap Setting Adjustment A	-	orsion Bar Da ap Setting		1				
Gap Setting Adjustment Adjustment Adjustment Adjustment Left Right Sec/Rev (Meter Reading) t Δm, Microns Sec ⁷ Sec ⁷ Sec ⁷ In O75 Sec ⁷ In O746		ap Setting		= 1.851	X 10' Dyne-	.cm/Micron		
Microns Left Right Sec/Rev (Meter Reading) Sec-1 -123 0.3 3.0 167.0 18.0 1.075 -110 0.3 2.0 16.7 65.0 10.746 -102 0.3 2.0 16.7 40.5 10.746 -103 0.3 1.0 16.7 40.5 10.746 -104 0.3 1.0 1.67 84.0 10.7456 -105 0.3 1.0 1.67 84.0 10.7456 -107 107 107 107 107 107 107 107 107 107	+		Transm	ission			p 20040	# # 1 2 2 2 1 V
-123 0.3 3.0 167.0 18.0 1.075 -110 0.3 2.0 16.7 65.0 10.746 -102 0.3 2.0 16.7 40.5 10.746 - 88 0.3 2.0 16.7 10.746 - 66 0.3 1.0 1.67 66.0 10.746 - 44 0.3 1.0 1.67 34.0 10.7456 - 45 0.3 1.0 1.67 34.0 10.7456 - 122 0.3 1.0 1.67 30.0 10.746 - 123 0.3 2.0 16.7 75.0 10.746 - 103 2.0 16.7 75.0 10.745 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 16.7 75.0 10.7456 - 103 2.0 103 2.0 10.7456 - 103 2.0	LL.	Microns	Left	Right	Sec/Rev	(Meter Reading)	Sec-1	Centipoise
-110 0.3 2.0 16.7 65.0 10.746 -102 0.3 2.0 16.7 65.0 10.746 - 88 0.3 2.0 16.7 65.0 10.746 - 66 0.3 1.0 1.67 66.0 10.7456 - 44 0.3 1.0 1.67 34.0 10.7456 - 122 0.3 1.0 1.67 34.0 10.7456 - 123 0.3 2.0 16.7 75.0 10.746 - 123 0.3 2.0 16.7 75.0 10.746 - 123 0.3 2.0 16.7 75.0 10.746 - 124 0.3 2.0 16.7 75.0 10.7456 - 125 10.7456 - 127 0.3 2.0 16.7 75.0 10.7456 - 128 0.3 2.0 16.7 75.0 10.7456 - 128 0.3 2.0 16.7 75.0 10.7456 - 128 0.3 2.0 16.7 75.0 10.7456 - 128 0.3 2.0 16.7 75.0 10.7456 - 129 0.5 10.7456 - 129 0.5 10.7456	2.5	-123		0	0.731	0 80	1 075	947 5
-102 0.3 2.0 16.7 40.5 10.746 - 88 0.3 2.0 16.7 19.3 10.746 - 66 0.3 1.0 1.67 66.0 107.456 - 44 0.3 1.0 1.67 34.0 107.456 - 45 0.3 1.0 1.67 21.0 107.456 - 13.88 10.7456 - 14. 0.3 2.0 16.7 75.0 10.746 - 10.746 - 10.746 - 10.746 - 10.746 - 10.746 - 10.746 - 10.746 - 10.746 - 10.7456 - 10		-110	0.3	2.0	16.7	65.0	10.746	342.1
- 66 0.3 2.0 16.7 66.0 10.746 - 44 0.3 1.0 1.67 34.0 10.7456 - 22 0.3 1.0 1.67 21.0 10.7456 - 13.88 10.7456 - 14. 0.3 2.0 16.7 21.0 10.7456 - 13.88 10.7456 - 10.7456	4.	-102	0.3	2.0	16.7	40.5	10.746	213.2
-123 0.3 1.0 1.67 34.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 21.0 107.456 1.67 22.5 107.456 1.67 22.5 107.456 1.67 4.56 1.67 22.5 107.456 1.67 4.57 4.56 1.67 4.57 4.57 4.57 4.57 4.57 4.57 4.57 4.5	-2	889	0.0	2.0	16.7	19.3	10.746	101.6
-123 0.3 1.0 1.67 21.0 107.456 13.88 107.456 1	5.3		0.3	0.1	1.67	34.0	107.456	17.9
-123 0.3 1.0 1.67 13.88 107.456 -123 0.3 2.0 16.7 75.0 10.746 -100 0.3 2.0 16.7 30.0 10.746 10.746 10.746 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456	0.3	- 22	0.3	1.0	1.67	21.0	107.456	11.1
-123 0.3 2.0 16.7 75.0 10.746 -110 0.3 2.0 16.7 30.0 10.746 10.745 17.5 10.745 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456	0.3	4 .	0.3	0.1	1.67	13.88	107.456	7.3
10.746 17.5 10.746 10.746 10.745	5.2	-123	0.3	2.0	16.7	75.0	10.746	394.8
10.746 10.746 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456 10.7456	0.1	-110	0.3	2.0	16.7	30.0	10.746	157.9
107.456 107.456 107.456 107.456 107.456	9.4	-102	0.3	2.0	16.7	17.5	10.746	92.1
107.456 107.456 107.456 107.456 107.456	5.2			0.1	1.67	90.5	107.456	47.6
22.5 107.456 13.5 107.456 9.25 107.456	0		0.3	1.0	1.67	40.0	107.456	21.1
9.25 107.456			0.9		1.67	22.5	107.456	11.8
	2.3				1.67	9.25	107.456	4

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

-		 	
Microns d 21)	Viscosity Centipoise	27.8 18.8 18.7 19.7 12.1 12.1 12.3 12.3 12.3 12.3 12.3 12.3	
Gap Setting 91 Mic RB # 55423 (16 and 21)	Shear Rate Sec-1	107.456 107.456 107.456 107.456 107.456 107.456 107.456 107.46 107.46 107.456 107.456 107.456	
RB #	∆m, Microns (Meter Reading)	52.8 35.8 35.8 10.8 10.8 10.0 10.0 10.0 10.0	State Court
2° 0' 2 1141 X 10'	t Sec/Rev	1.67 1.67 1.67 1.67 1.67 1.67 1.67 1.67	
Cone Angle 2° 0' Cone Nr 1141 K _T = 1.851 X 10'	Transmission Left Right	00000000 0000000	
	Trans		
5.0 cm 865 Torsion Bar Data:	Gap Setting Adjustment Microns	- 100 - 100	
	tures	-65.2 -65.2 -65.2 -65.2 -65.2 -70.3 -70.3	
TA: Diameter Flat Nr (Cont'd)	Test Temperatures Millivolts °F	1. 65 1. 65	
PLATEN DATA: TABLE D-2 (Cont'd)	Sample Number	SH-5A SH-5A SH-5A SH-5A SH-28	

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

	+	
Microns 7)	Viscosity Centipoise	31,581.8 7,369.1 3,184.5 1,074.8 283.2 99.0 47.9 26.8 30,818.6 7,174.3 1,094.8 1,094.8 1,094.8 1,094.8
Gap Setting 91 NRB # 55424 (25, 27)	Shear Rate Sec-1	1.075 1.075 1.075 1.075 10.746 10.746 10.746 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075 1.075
RB # Dyne-cm/Micron	Δm, Microns (Meter Reading)	600.0 140.0 60.5 20.8 20.8 136.3 136.3 59.0 52.5 19.5 19.5
	t Sec/Rev	167.0 167.0 167.0 167.0 16.7 1.67 1.67 1.67.0 167.0 167.0 167.0
Cone Angle 2°0' Cone Nr 1141 K _T = 1.851 X 10'	Transmission Left Right	
0 0	Trans	
5.0 cm 865 Torsion Bar Data:	Gap Setting Adjustment Microns	-123 -110 -102 -102 - 66 - 66 - 66 - 66 - 66
	tures °F	
TA: Diameter Flat Nr (Cont'd)	Test Temperatures Millivolts °F	1. 65 1. 1. 65 1. 1. 18 1. 1. 18 1. 1. 18 1. 1. 18 1. 1. 18 1. 18 1. 1. 18 1.
PLATEN DATA: TABLE D-2 (Cont'	Sample	*****

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

	Flat Nr		865	Con	Cone Angle	1141	Gap RB	Gap Setting 91 Mic RB # 55423 (24 and 25)	Microns 1 25)
TABLE D-	TABLE D-2 (Cont'd)		Torsion Bar Data:		K _T = 1.851 x 10'		Dyne-cm/Micron		
1	Test Tempera	emperatures	Gap Setting	Transi	Transmission	-	3	6	7
Sample	Millivolts	L 0	. Adjustment Microns	Left	Right	Sec/Rev	(Meter Reading)	Sec 1	Centipoise
			35 3					8000	
SH-30A	-1.93	-65.2		0.3	3.0	167.0	270.0	1.075	14,211.9
SH-30A	-1.65	F50.1		0.3	3.0	167.0	56.5	1.075	2,974.0
SH-30A	-1.47	-40.4		0.3	3.0	167.0	31.5	1.075	1,658.1
SH-30A	-1.18	F25.2		0.3	3.0	167.0	13.5	1.075	710.6
SH-30A	19.0-	0	99 -	0.3	2.0	16.7	32.0	10.746	168.4
SH-30A	-0.14	25.3		0.3	2.0	16.7	13.0	10.746	4.89
SH-30A	-0.14	25.3	1	0.3	1.0	1.67	128.0	107.456	4.79
SH-30A	0.40	50.3		0.3	1.0	1.67	65.0	107.456	34.2
SH-30A	0.84	70.3	4 -	0.3	1.0	1.67	39.0	107.455	20.5
3H-31A	-1.93	-65.2	-123	0.3	3.0	167.0	89.0	1.075	4.684.7
5H-31A	-1.65	-50.1	-110	0.3	3.0	167.0	28.5	1.075	1,500.1
3H-31A	-1.47	40.4	-102	0.3	3.0	167.0	17.8	1.075	936.9
3H-31A	-1.18	-25.2	- 88	0.3	2.0	16.7	68.0	10.746	357.9
SH-31A	-0.67	0	1	0.3	2.0	16.7	23.8	10.746	125.3
SH-31A	-0.14	25.3	•	0.3	2.0	16.7	10.0	10.746	52.6
SH-31A	-0.14	25.3	•	0.3	1.0	1.67	100.0	107.456	52.6
SH-31A	0,40	50.3	1	0.3	1.0	1.67	46.0	107.456	24.2
SH-31A	0.84	70.3	4 -	0.3	1.0	1.67	30.0	107.456	15.8

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Microns 27)	Viscosity Centipoise	2,895.0 894.8 5500.0 254.3 884.4 403.7 13.4 149.9 149.9 169.9 169.9 17.9
Gap Setting 91 RB # 55423 (26 and	Shear Rate Sec-1	1.075 1.075 10.746 10.746 10.746 107.456 107.456 10.746 10.746 10.746 10.746 10.746 10.746 10.746 10.746 10.746
Gap RB Dyne-cm/Micron	Δm, Microns (Meter Reading)	25.0 17.0 17.0 10.0 10.0 10.0 10.0 10.0 10
2°0'2 1141 X 10'	Sec/Rev	167.0 167.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0 16.7.0
Cone Angle Cone Nr K _T = 1.851	Transmission Left Right	0.000000 0.0000000
	Trans	
5.0 cm 865 Torsion Bar Data:	Gap Setting Adjustment Microns	1 1 2 3 4 5 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6
N rer	stures °F	-65.2 -70.1 -70.1 -70.1 -70.3
TA: Diameter Flat Nr (Cont'd)	Test Temperatures Millivolts °F	1.1.1.9.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.
PLATEN DATA: TABLE D-2 (C	Sample	SH-32A SH-32A SH-32A SH-32A SH-32A SH-32A SH-32A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A SH-33A


WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)


Diameter 5.0 cm Cone Angle 2° 0' 22" Gap Setting 91 Microns	Flat Nr 865 Cone Nr 1141 RB # 55424 (7) and 55423 (28)	Torsion Bar Data: $K_T = 1.851 \times 10^{1}$ Dyne-cm/Micron	Transmission	Adjustment Left Right Sec/Rev (Meter Reading) Sec-1 Centipoise	-65.2	-50.1 -110 0.3 3.0 167.0 85.0 1.075	F40.4 -102 0.3 3.0 167.0 41.0 1.075	0 - 66 0.3 2.0 16.7 44.5 10.746	25.3 - 44 0.3 2.0 16.7 18.0 10.746	75.3 - 72 0.3 1.0 1.67 75.3 107.456 39.6 70.3 - 4 0.3 1.0 1.67 45.5 107.456 23.9	-65.2 -123 0.3 2.0 16.7 86.0 10.746	-40.4 · 102 0.3 2.0 16.7 26.3 10.746	-25.2 - 88 0.3 2.0 16.7 14.5 10.746	0 - 66 0.3 1.0 1.67 65.0 107.456	25.3 - 44 0.3 1.0 1.67 34.0 107.456	50.3 - 22 0.3 1.0	
1	'	Ĕ		e.	-65.2	-50.1	140.4	7:00	25.3	70.3	-65.2	-40.4	-25.2	0	25.3	50.3	
	Flat	(Cont'd)	Test Temper	Millivolts	-1.93	-1.65	-1.47	-0.67	-0.14	0.40	-1.93	-1.47	-1.18	-0.67	-0.14	0.40	
PLATEN DATA:		TABLE D-2 (Cont'd)	-	Sample Number	SH-29A	SH-29A	SH-29A	SH-29A	SH-29A	SH-29A SH-29A	SH-22A	SH-22A	SH-22A	SH-22A	SH-22A	SH-22A SH-22A	

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Microns	Viscosity Centipoise	189.5 62.7 62.7 19.2 19.2 19.2 70.0 70.0 73.7 139.5 7.6 7.6
Gap Setting 91 RB # 55424 (9, 10)	Shear Rate Sec-1	10.746 10.746 107.456 107.456 107.456 107.456 10.746 10.746 10.746 10.746 10.746 10.746 10.746
Gap RB Dyne-cm/Micron	∆m, Microns (Meter Reading)	36.0 118.8 118.8 37.8 10.0 14.0 14.0 14.0 14.0 14.0 14.0 14.0
1 2 -	Sec/Rev	16.7 1.67 1.67 1.67 1.67 1.67 1.67 1.67
Cone Angle 2° 0' Cone Nr 114° $K_{\bar{T}} = 1.851 \times 10^{\circ}$	Transmission Left Right	0000000 000000
100	Trans	
865 Torsion Bar Data:	Gap Setting Adjustment Microns	1123 1123 1123 1123 124 124 123 123 123 123 123 123 123 123 123 123
	tures	25.2 25.3 25.3 70.3 70.3 70.3
Diame Flat	Test Temperatures Millivolts °F	-1.93 -1.65 -1.16 -0.14 -0.14 -0.14 -1.65 -1.16 -0.67 -1.17 -1.18 -1.65 -1.19 -1.19 -1.10
PLATEN DATA: TABLE D-2 (Cont'd	Sample Number	SH-26A SH-26A SH-26A SH-26A SH-26A SH-26A SH-26A SH-37 SH-37 SH-37 SH-37 SH-37 SH-37 SH-37

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)





AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Cone Nr 1141 Data: K _T = 1.851 x 10' Dyne-cm/Micron Transmission	Shear Rate **S	-123 0.3 3.0 167.0 217.5 -110 0.3 3.0 167.0 67.8	-102 - 88 0.3 2.0 167.0	- 66 0.3 2.0 16.7 35.3	50.3 - 22 0.3 1.0 1.67 70.0 107.456 70.3 - 4 0.3 1.0 1.67 43.0 107.456	-65.2 -123 0.3 2.0 16.7 62.3 10.746 -50.1 -110 0.3 2.0 16.7 30.0 10.746 -40.4 -102 0.3 2.0 16.7 30.0 10.746 -25.2 -86 0.3 1.0 1.67 115.5 107.456 25.3 -44 0.3 1.0 1.67 29.5 107.456 70.3 -22 0.3 1.0 1.67 11.5 107.456
TABLE D-2 (Cont'd)	Millivolts	1.9	1.4.	-0.6	0.40	-1.93 -1.65 -1.17 -1.18 -0.67 0.40

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Test Temperatures Gap Setting Transmission to Am, Microns Shear Rate Adjustment Left Right Sec/Rev (Meter Reading) Sec-I Hicrons Left Right Sec/Rev (Meter Reading) Sec-I High										
Temperatures Gap Setting Transmission the Many Microns Shear Rate Volts of Microns Left Right Sec/Rev (Meter Reading) Sec-land Se	TABLE D-	2 (Cont'd)		Torsion Bar Da		1.851	X 10' Dyne-	cm/Micron		
Hillyolts		-	atures	Gap Setting	Trans	mission				4
-1.93 -65.2 -123 0.3 3.0 167.0 555.0 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 126.8 1.075 -1.18 -25.2 -88 0.3 3.0 167.0 57.0 1.075 -0.67 0.40 55.3 -44 0.3 2.0 167.0 55.3 10.746 -0.14 25.3 -44 0.3 2.0 167.7 55.3 10.746 -1.93 -65.2 -123 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -102 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -102 0.3 3.0 167.0 49.8 1.075 -1.65 -50.1 -102 0.3 1.0 16.7 52.8 1.075 -1.07 -1.07 -1.07 17.8 107.456 -0.14 25.3 -44 0.3 1.0 1.67 56.0 107.456 -0.19 50.3 -22 0.3 1.0 1.67 56.0 107.456 -0.10 50.3 -22 0.3 1.0 1.67 56.0 107.456	Number	Millivolts		Adjustment Microns	Left	Right	Sec/Rev	Am, Microns (Meter Reading)	Sec-1	Centipoise
-1.65 -50.1 -110 0.3 3.0 167.0 126.8 1.075	.	-1.93	-65.2	-123	0.3	3.0	167.0	555.0	1.075	29,213.1
-1.18 -25.2 - 88 0.3 3.0 167.0 22.0 1.075 -0.67 0 - 66 0.3 2.0 16.7 53.3 10.746 -0.40 50.3 - 44 0.3 2.0 16.7 20.0 10.746 0.40 50.3 - 22 0.3 1.0 1.67 94.0 107.456 -1.93 -65.2 -123 0.3 3.0 167.0 25.8 1.075 -1.47 -40.4 - 102 0.3 3.0 167.0 48.8 1.075 -1.48 -25.2 - 88 0.3 2.0 16.7 92.5 10.746 -0.67 0 - 66 0.3 2.0 16.7 92.5 10.746 -0.14 25.3 - 44 0.3 1.0 1.67 80.0 107.456 -0.40 50.3 - 22 0.3 1.0 1.67 80.0 107.456 -0.84 70.3 - 4 0.3 1.0 1.67 36.0 107.456	S HS	-1.65	-70.4	-102	0.0	3.0	167.0	126.8	1.075	6,674.3
-0.14 25.3 - 44 0.3 2.0 16.7 20.0 10.746 0.40 50.3 - 22 0.3 1.0 1.67 94.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 94.0 107.456 0.84 70.3 - 4 0.3 1.0 167.0 171.0 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 48.8 1.075 -1.47 -40.4 -102 0.3 3.0 167.0 25.8 1.075 -1.18 -25.2 - 88 0.3 2.0 167.0 25.8 1.0746 -0.67 0 - 66 0.3 2.0 16.7 29.3 10.746 -0.14 25.3 - 44 0.3 1.0 1.67 60.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 60.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 80.0 107.456	SH HS	-1.18	-25.2	88 	0.3	3.0	16.7	22.0	1.075	1,158.0
0.84 70.3 - 4 0.3 1.0 1.67 56.0 107.456 -1.93 -65.2 -123 0.3 3.0 167.0 48.8 1.075 -1.65 -50.1 -110 0.3 3.0 167.0 48.8 1.075 -1.47 -40.4 -102 0.3 3.0 167.0 48.8 1.075 -1.47 -40.4 -102 0.3 3.0 167.0 25.8 1.076 -1.18 -25.2 -88 0.3 2.0 16.7 92.5 10.746 -0.67 0 -66 0.3 2.0 16.7 92.5 10.746 -0.14 25.3 - 44 0.3 1.0 1.67 29.3 10.7456 0.40 50.3 - 22 0.3 1.0 1.67 36.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 36.0 107.456	* *	-0.1¢	25.3	- 44	0.3	2.0	1.67	20.0	10.746	105.3
-1.93 -65.2 -123 0.3 3.0 167.0 171.0 1.075 1.65 -50.1 -110 0.3 3.0 167.0 48.8 1.075	H.	9.84	70.3		0.3	<u>.</u>	1.67	56.0	107.456	29.5
-1.47 -40.4 -102 0.3 3.0 167.0 25.8 1.075 -1.18 -25.2 - 88 0.3 2.0 16.7 92.5 10.746 -0.67 0 - 66 0.3 2.0 16.7 92.5 10.746 -0.14 25.3 - 44 0.3 1.0 1.67 117.8 107.456 0.40 50.3 - 22 0.3 1.0 1.67 36.0 107.456	SH-39 SH-39	-1.93	-65.2	-123	0.3	3.0	167.0	171.0	1.075	9,000.8
-0.67 0.3 2.0 16.7 29.3 10.746 -0.14 25.3 -44 0.3 1.0 1.67 117.8 107.456 0.40 50.3 - 22 0.3 1.0 1.67 60.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 36.0 107.456	SH-39	-1.47	40.4	-102	0.9	20.0	167.0	25.8	1.075	1,358.0
-0.14 25.3 - 44 0.3 1.0 1.67 117.8 107.456 0.40 50.3 - 22 0.3 1.0 1.67 60.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 36.0 107.456	SH-39	-0.67	7.5.7	8 99	0.3	2.0	16.7	29.5	10.746	154.2
SECULAR SECU	SH-39 SH-39 SH-39	-0.14 0.40 0.84	25.3 50.3 70.3	* 52 *	0.3	000	1.67	117.8 60.0 36.0	107.456 107.456 107.456	62.0 31.6 18.9
			19141					S. S	ALCO OFFER	

AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Test Temperatures Gap Setting Transmission t Adjustment Adjustment Adjustment Left Right Sec/Rev (Meter Reading) Sec-last Hicrons Left Right Sec/Rev (Meter Reading) Sec-last Left Left Right Sec/Rev (Meter Reading) Sec-last Right Sec/Rev (Meter Reading) Sec-last Right Sec-last Right Sec-last Right Sec-last Right Sec-last Right Sec/Rev (Meter Reading) Sec-last Right Right Sec-last Right	P-2 (Cont'd) 1.9 -1.6 -1.4 -1.9 -1.9 -1.9 -1.9 -1.1 -1.1	atur	Torsion Bar Da	sta: Kr					
Test Temperatures Gap Setting Transmission t Adjustment Adjustment Left Right Sec/Rev (Meter Reading) Sec-1 -1.93 -65.2 -123 0.3 3.0 167.0 82.5 1.075 -1.65 -50.1 -110 0.3 2.0 16.7 122.0 10.746 -1.18 -25.2 -88 0.3 2.0 16.7 122.0 10.746 -0.14 25.3 -44 0.3 1.0 1.67 72.5 10.746 -1.193 -65.2 -123 0.3 1.0 1.67 72.0 10.746 -1.193 -65.2 -123 0.3 2.0 16.7 17.4 10.746 -1.193 -65.2 -123 0.3 1.0 1.67 72.0 10.746 -1.193 -65.2 -123 0.3 2.0 16.7 123.0 10.746 -1.193 -65.2 -123 0.3 2.0 16.7 123.0 10.746 -1.193 -65.2 -123 0.3 2.0 16.7 143.0 10.746 -1.18 -20.3 -44 0.3 1.0 16.7 143.0 10.746 -1.18 -20.3 -44 0.3 1.0 16.7 143.0 10.745 -1.18 -20.3 -44 0.3 1.0 1.67 143.0 10.745 -1.18 -20.3 -44 0.3 1.0 1.67 143.0 10.745 -0.67 0 -66 0.3 1.0 1.67 143.0 10.745 -0.14 25.3 -44 0.3 1.0 1.67 143.0 10.745 -0.14 25.3 -44 0.3 1.0 1.67 13.5 10.745 -0.40 50.3 -44 0.3 1.0 1.67 13.5 10.745	Test 1	ratur			1.851		cm/Micron		
Hillivolts		-	Gap Setting	Transi	nission		1	6	A TOTAL
-1.93 -65.2 -123 0.3 3.0 167.0 82.5 1.075 -1.65 -50.1 -110 0.3 2.0 16.7 238.8 10.746 -1.47 -40.4 -102 0.3 2.0 16.7 122.0 10.746 -1.48 -25.2 -88 0.3 2.0 16.7 122.0 10.746 -0.14 25.3 -44 0.3 2.0 16.7 17.4 10.746 -0.14 25.3 -44 0.3 1.0 1.67 42.0 10.746 -1.93 -65.2 -123 0.3 2.0 16.7 123.0 10.746 -1.93 -65.2 -123 0.3 2.0 16.7 123.0 10.746 -1.47 -40.4 -102 0.3 2.0 16.7 123.0 10.746 -1.48 -25.2 -88 0.3 1.0 1.67 13.0 10.746 -1.49 -25.3 -44 0.3 1.0 1.67 13.0 10.746 -1.40 50.3 -22 0.3 1.0 1.67 13.0 10.745 -1.65 -50.1 -110 0.3 1.0 1.67 13.0 10.745 -1.65 -50.1 -110 0.3 1.0 1.67 13.0 10.745 -1.65 -50.1 -110 0.3 1.0 1.67 13.0 10.745 -1.67 -1.67 13.5 10.7456 -0.14 25.3 -44 0.3 1.0 1.67 13.5 10.7456 -0.84 70.3 -4 0.3 1.0 1.67 13.5 10.7456			Microns	Left	Right	Sec/Rev	(Meter Reading)	Sec-1	Centipoise
-1.65 +50.1 -110 0.3 2.0 16.7 238.8 10.746 -1.47 +0.4 -102 0.3 2.0 16.7 122.0 10.746 1		-65.2	-123	0.3	3.0	167.0	82.5	1.075	h 3h2 E
-1.18 -25.2 - 88 0.3 2.0 16.7 52.5 10.746 -0.67 0 - 66 0.3 2.0 16.7 77.4 10.746 10.746 -0.14 25.3 - 44 0.3 1.0 1.67 74.5 10.746		10.1	-110	0.3	2.0	16.7	238.8	10.746	1,257.0
-0.14 25.3 - 44 0.3 1.0 1.67 74.5 10.746 0.40 50.3 - 22 0.3 1.0 1.67 42.0 10.746 10.74		-25.2	88 -	0.00	2.0	16.7	52.5	10.746	276.3
-1.93 -55.2 -123 0.3 1.0 1.67 42.0 107.456 -1.65 -50.1 -110 0.3 2.0 16.7 123.0 10.746 -1.65 -50.1 -110 0.3 2.0 16.7 123.0 10.746 -1.47 -40.4 -102 0.3 2.0 16.7 123.0 10.746 -1.18 -25.2 -88 0.3 1.0 1.67 143.0 107.456 -0.14 25.3 -44 0.3 1.0 1.67 19.0 107.456 -0.40 50.3 -22 0.3 1.0 1.67 19.0 107.456 -0.84 70.3 -4 0.3 1.0 1.67 19.0 107.456	•	25.3	0 1	0.3	1.0	1.67	74.5	10.746	39.5
-1.93 -65.2 -123 0.3 2.0 16.7 123.0 10.746 -1.65 -50.1 -110 0.3 2.0 16.7 28.5 10.746 -1.47 -40.4 -102 0.3 2.0 16.7 28.5 10.746 -1.18 -25.2 - 88 0.3 1.0 1.67 143.0 107.456 -0.67 0 - 66 0.3 1.0 1.67 19.0 107.456 -0.14 25.3 - 44 0.3 1.0 1.67 19.0 107.456 0.40 50.3 - 22 0.3 1.0 1.67 13.5 107.456		3.5	- 72	0.3	9.9.	1.67	42.0 26.0	107.456	22.1 13.7
-1.47 +40.4 -102 0.3 2.0 16.7 44.5 10.746 10.3 1.0 1.67 13.5 10.7456		-65.2	-123	0.3	2.0	16.7	123.0	10.746	647.4
-0.67 0 -66 0.3 1.0 1.67 143.0 107.456 -0.14 25.3 - 44 0.3 1.0 1.67 1.67 197.456 -0.14 25.3 - 44 0.3 1.0 1.67 19.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 13.5 107.456 107.456		40.4	-110	0.3	2.0	16.7	28.5	10.746	234.2
-0.14 25.3 - 44 0.3 1.0 1.67 31.0 107.456 0.40 50.3 - 22 0.3 1.0 1.67 19.0 107.456 0.84 70.3 - 4 0.3 1.0 1.67 13.5 107.456		125.2	88 '	0.3	0.0	1.67	143.0	107.456	75.3
0.84 70.3 - 22 0.3 1.0 1.67 19.0 107.456 107.456 107.456		25.3	31	0.3	20	1.67	31.0	107.456	32.3
		76.3	7	0.3	0.0	1.67	13.5	107.456	10.0

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

Test Temperatures Gap Setting Transmission Adjustment Adjustment Left Right Microns -1.93 -65.2 -123 0.3 2.0 -1.47 -40.4 -102 0.3 1.0 -6.67 0 -6.07 0 -66 0.3 1.0 -6.14 25.3 -44 0.3 1.0 -6.14 25.3 -22 0.3 1.0 -2.20 -80.0 -123 0.3 2.0 -1.93 -65.2 -123 0.3 1.0	_		
Adjustment Left Right Microns Left Right Microns -1.93 -65.2 -123 0.3 2.0 -1.65 -50.1 -110 0.3 2.0 -1.65 -50.1 -102 0.3 1.0 -0.67 0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -66 0.3 1.0 -65.2 -22 -4 0.3 1.0 -1.93 -65.2 -123 0.3 1.0 -1.93 -65.2 -123 0.3 1.0 -1.93 -65.2 -123 0.3 1.0 -1.0 -1.0 -1.0 -1.0 -1.0 -1.0 -1.0			4
-1.93 -65.2 -123 0.3 2.0 -1.65 -50.1 -110 0.3 2.0 -1.47 -40.4 -102 0.3 1.0 -1.18 -25.2 -88 0.3 1.0 -0.14 25.3 -44 0.3 1.0 -0.14 50.3 -22 0.3 1.0 0.84 70.3 -44 0.3 1.0 -2.20 -80.0 -123 0.3 1.0 -1.93 -65.2 -123 0.3 1.0	3	Shear Rate	Viscosity
-1.65 -50.1 -110 0.3 2.0 -1.47 -110 0.3 2.0 -1.18 -25.2 -88 0.3 1.0 -0.67 0 -66 0.3 1.0 -0.14 25.3 -44 0.3 1.0 0.40 50.3 -22 0.3 1.0 0.84 70.3 -22 0.3 1.0 -2.20 -80.0 -123 0.3 1.0 -1.93 -65.2 -123 0.3 1.0	26.0	10.746	294.7
-1.18 -25.2 - 88 0.3 1.0 -0.67 0 - 66 0.3 1.0 -0.14 25.3 - 44 0.3 1.0 0.40 50.3 - 22 0.3 1.0 0.84 70.3 - 4 0.3 1.0 -2.20 -80.0 -123 0.3 2.0 -1.93 -65.2 -123 0.3 1.0	157.5	10.746	129.0 82.9
-0.14 25.3 - 44 0.3 1.0 0.40 50.3 - 22 0.3 1.0 0.84 70.3 - 4 0.3 1.0 -2.20 -80.0 -123 0.3 2.0 -1.93 -65.2 -123 0.3 1.0	39.0	107.456	42.0
0.40 50.3 - 22 0.3 1.0 0.84 70.3 - 4 0.3 1.0 -2.20 -80.0 -123 0.3 2.0 -1.93 -65.2 -123 0.3 1.0	20.0	107.456	10.5
-2.20 -80.0 -123 0.3 2.0 -1.93 -65.2 -123 0.3 1.0	9.5	107.456	2.0
-1.93 -65.2 -123 0.3 1.0	41.5	10.746	218.4
	200.0	107.456	105.2
-1.65 -50.1 -110 0.3 1.0	0.78	107.456	33.7
-1.18 -25.2 - 88 0.3 1.0	37.0	107.456	19.5
-0.67 0 - 66 0.3 1.0	2.82	107.456	7.5
SH-43 0.84 70.3 - 4 0.3 1.0 1.67	6.0	107.456	6,6

AFAPL-TR-76-17

Viscosity Centipoise 34,213.6 7,342.8 3,079.2 1,079.0 190.0 195.2 frozen frozen 17,633.2 1,105.4 268.8 103.3 46.1 28.4 RB # 55422 (4) and 55418 (17) Microns Shear Rate 6 WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE) 1.075 1.075 1.075 10.746 10.746 107.456 1.075 1.075 1.075 1.075 10.746 10.746 107.456 Gap Setting Am, Microns (Meter Reading) 335.0 21.0 5.1 50.5 19.63 87.5 54.0 58.5 56.0 56.0 57.0 57.0 Dyne-cm/Micron sec/Rev 2° 0' 22" 167.0 167.0 167.0 167.0 16.7 16.7 1.67 167.0 167.0 167.0 167.0 16.7 16.7 1141 KT = 1.851 X 101 Cone Angle Right Transmission K Cone Left Data: Gap Setting Adjustment Microns Torsion Bar -123 -102 -102 - 88 - 88 - 66 - 44 - 22 - 22 5 5.0 865 65.2 25.0 25.0 25.0 70.0 70.0 25.2 25.2 25.3 26.3 26.3 Test Temperatures . Diameter Flat Nr Millivolts 0.40 TABLE D-2 (Cont'd) PLATEN DATA: Sample Number S S S S S S S S S

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

	Test Tempera	emperatures	Gap Setting	Transi	Transmission				a
Sample	Millivolts		Adjustment Microns	Left	Right	Sec/Rev	Am, Microns (Meter Reading)	Shear Rate Sec-1	Viscosity
SHA SHA SHA SHA SHA SHA SHA SHA	-1.65 -1.47 -1.18 -1.18 -0.67 -0.67 -0.67	-65.2 -50.1 -25.2 -25.3 50.3 70.3	- 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	0000000	0.000000	167.0 167.0 167.0 167.0 16.7 16.7	670.0 130.0 66.5 21.8 55.0 21.0 95.0	1.075 1.075 1.075 1.075 10.746 10.746 107.456	35,266.4 6,842.7 3,500.2 1,147.5 110.5 50.0
8	1.93 1.147 1.18 1.067 1.067 1.067 1.067 1.068	65.2 -50.1 -25.2 -25.2 -0 -0 -0 -0 -0 -0 -0 -0 -0 -0 -0 -0 -0	4 4 4 4 4 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7	00000000	0.000000	167.0 167.0 167.0 167.0 16.7 1.67	503.0 132.5 58.0 28.0 52.8 18.3 87.8	1.075 1.075 1.075 1.075 10.746 10.746 107.456	26,476.0 6,974.3 3,052.9 1,052.7 1,052.7 96.3 46.2

AFAPL-TR-76-17

WEISSENBERG RHEOGONIOMETER VISCOSITY DATA (CONE AND PLATE)

TABLE D-2 (Cont'd)	(Cont'd)		Torsion Bar Data:		Kr = 1.051 X 10	ol v	Dyne-cm/Micron		es Ho
	Test Temperatures	stures	Gap Setting	Trans	Transmission				4
Sample Number	Millivolts	!	Adjustment Microns	Left	Right	Sec/Rev	Am, Microns (Meter Reading)	Sec-1	Centipoise
SHC	-1.93	-65.2	-123	0.3	3.0	167.0	498.0	1.075	26,212.9
SHS SHS	-1.65	-40.4	-110 -102	0.3	3.0	167.0	127.8	1.075	6,726.9
SHC	-1.18	-25.2	88 	0.3	3.0	167.0	19.5	1.075	1,026.4
SH C SH C	-0.14 0.40 0.84	25.3 50.3 70.3	+ 53 E	0.3	1.0	1.67	19.3 87.5 50.0	10.746 107.456 107.456	101.6 46.1 26.3
88	-1.93	-65.2	-123	0.3	3.0	167.0	750.0	1.075	39,477.3
25 SE	-1.18	-25.2	788 1 - 1	6.3.3	2.00	167.0	74.5 24.8 60.5	1.075	3,921.4 1,305.4 318.5
S S S	0.00	25.3 20.3 70.3			1.0	1.67	21.3 100.0 55.0	107.456	112.1 52.6 29.0
							30 (a) (b) (b) (b) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c		

APPENDIX E

VISCOSITY OF SHELLDYNE-H BLENDS AT VARIOUS TEMPERATURES

The data tabulated in Appendix D have been reduced and are tabulated in this section. Since all of the test blends were determined to be Newtonian, there is no variation of viscosity with shear rate; therefore, no reference is made here to the shear rates used in the various determinations. For all testing, the shear rates were either 1.074, 10.746 or 107.456 sec⁻¹ and can be found in the data presentation in Table D-2. The volume percentages were calculated at 60°F.

TABLE E-1

VISCOSITY OF SHELLDYNE-HATOLUENE BLENDS AT VARIOUS TEMPERATURES

	VISCOSIT	VISCOSITY, CENTIPOISE AT VARIOUS VOLUME % TOLUENE	SE AI VAKIU	US VOLUME &	TOLUENE
Temperature, °F	5.1%	12.3%	29.1%	35.1%	53.7%
-65	4,489.9	1947.5	289.5	110.5	27.8
-50	1,500.1	8.499	138.4	57.9	18.8
-40	842.2	381.6	92.1	40.0	13.7
-25	342.1	189.5	54.0	25.0	9.7
0	115.8	70.4	24.5	13.7	5.7
25	51.3	34.2	15.8	10.0	3.9
50	25.3	19.7	10.4	7.4	3.0
70	17.9	13.9	8.7	8.9	2.6

TABLE E-2

VISCOSITY OF SHELLDYNE-H/JP-4 BLENDS AT VARIOUS TEMPERATURES

	VISCOSIT	VISCOSITY, CENTIPOISE AT VARIOUS VOLUME % TOLUENE	SE AT VARIOU	S VOLUME %	TOLUENE
Temperature, °F	\$6.9	13.5%	31.9%	42.18	58.4%
-65	7,658.6	2763.4	336.9	157.9	55.3
-50	2,184.4	888.5	145.4	81.0	31.8
04-	1,131.7	539.5	97.4	9.95	23.2
-25	447.4	244.8	9.95	34.2	15.3
0	147.4	86.9	26.3	17.4	9.0
25	61.8	39.0	16.5	10.7	6.7
50	30.0	21.3	10.5	7.1	6.4
70 64-25-38-43-5	20.0	14.4	8.2		3.9

TABLE E-3

VISCOSITY OF SHELLDYNE-H/METHYLCYCLOHEXANE BLENDS AT VARIOUS TEMPERATURES

	VISCOSI	VISCOSITY, CENTIPOISE, AT VARIOUS VOLUME & MCH	ISE, AT VAR	IOUS VOLUME	% MCH
Temperature, °F	6.9%	13.5%	31.9%	43.1%	58.4%
-65	6,043.1	2,237.0	321.1	167.4	42.1
-50	1,805.4	835.9	154.2	88.2	26.3
04-	968.5	479.0	104.6	63.2	20.7
-25	407.9	227.9	59.2	39.5	14.7
0	134.2	82.9	29.7	22.6	8.2
25	57.9	39.5	21.1	14.7	4.5
90	29.0	21.8	13.2	9.7	3.4
70	19.5	15.3	10.5	7.9	3.0

TABLE E-4

VISCOSITY OF SHELLDYNE-H/TETRALIN BLENDS AT VARIOUS TEMPERATURES

	VISCOSIT	Y, CENTIPOI	SE, AT VARI	VISCOSITY, CENTIPOISE, AT VARIOUS VOLUME % TETRALIN	TETRALIN
Temperature, °F	5.5%	10.9%	26.8%	37.18	52.3%
-65	13,159.1	7,974.4	1,710.7	974.5	394.8
-50	3,921.4	2,158.1	8.499	342.1	157.9
-40	1,631.7	1,042.2	329.0	213.2	92.1
-25	658.0	426.4	152.6	9.101	9.74
0	189.5	133.2	58.6	34.7	21.1
25	71.1	55.3	25.3	17.9	11.8
50	32.9	26.3	14.2	1.11	7.1
70	20.5	16.8	9.7	7.3	6.4

TABLE E-5

VISCOSITY OF SHELLDYNE-H/TRANS-DECALIN BLENDS AT VARIOUS TEMPERATURES

	VISCOSI	TY, CENTIPO	ISE AT VARIO	VISCOSITY, CENTIPOISE AT VARIOUS VOLUME & T-DECALIN	T-DECALIN
Temperature, °F	5.9%	11.9%	29.0%	39.7%	54.8%
-65	11,448.4	6,105.8	1,210.6	509.5	189.5
-50	3,568.7	2,000.2	454.3	207.9	7.46
-40	1,789.6	1,015.9	276.3	139.5	62.5
-25	643.7	421.1	146.3	79.0	38.3
0	185.8	143.7	53.7	33.7	19.2
25	72.6	57.9	26.3	18.8	11.6
90	26.8	29.0	15.2	10.8	7.4
70	22.6	18.2	1:1	7.6	5.5

TABLE E-6

VISCOSITY OF SHELLDYNE-H/TETRAHYDRO-METHYLCYCLOPENTADIENE DIMER BLENDS

AT VARIOUS TEMPERATURES

ISCOSITY, CENTIPOISE AT VARIOUS VOLUME & TH-MCPD DIMER	11.5% 27.8% 38.3% 53.7 100%	4,211.9 4,684.7 2,895.0 1,410.7 493.7	2,974.0 1,500.1 894.8 493.7 121.1	1,658.1 936.9 500.0 289.5 76.3	710.6 357.9 254.3 149.9 43.4	168.4 125.3 88.4 60.5 21.5	68.4 52.6 40.5 29.2 12.3	34.2 24.2 20.3 15.9 7.4	20.5 15.8 13.4 11.1 5.3
Y, CENTIPOISE AT VA		14,211.9 4,6							
VISCOSITY	5.78	18,686.0	4,474.1	2,158.1	947.5	234.2	94.7	39.6	23.9
	Temp., °F	-65	-50	04-	-25	0	25	50	70

TABLE E-7

VISCOSITY OF SHELLDYNE-H/ISOBUTYLBENZENE BLENDS AT VARIOUS TEMPERATURES

	VISCO	SITY, CENTI	POISE AT VA	VISCOSITY, CENTIPOISE AT VARIOUS VOLUME % IBB	8 188
Temperature, °F	6.2%	12.3%	29.6%	40.3%	55.8%
-65	9,000.8	4,342.5	4.7.4	294.7	105.2
-50	2,568.7	1,257.0	234.2	129.0	45.8
04-	1,358.0	642.2	150.0	82.9	33.7
-25	486.9	276.3	75.3	42.0	19.5
0	154.2	91.6	32.3	20.5	9.7
25	62.0	39.2	16.3	10.5	5.7
90	31.6	22.1	10.0	6.3	3.9
70	18.9	13.7	7.1	5.0	3.2

TABLE E-8

R

VISCOSITY OF SHELLDYNE-H - LOT #LR-11410-103

		Vi	scosity, Centi	poise	— ——			
Temp., °F	Run Nr 1	Run Nr 2	Run Nr 3	Run Nr 4	Average			
-65 -50 -40 -25 0 25 50 70	31,581.8 7,369.1 3,184.5 1,094.8 283.2 99.0 47.9 26.8	30,818.6 7,174.3 3,105.5 1,094.8 276.3 102.6 47.9 27.4	29,213.1 5,674.3 3,000.3 1,158.0 280.6 105.3 49.5 29.5	34,213.6 7,342.8 3,079.2 1,079.0 294.8 100.0 49.5 28.9	31,456.8 7,140.1 3,092.4 1,106.7 283.7 101.7 48.7 28.2			

TABLE E-9
VISCOSITY OF VARIOUS SHELLDYNE-H BATCHES

	SHA	SHB	SHC	SHD
31,456.8	35,266.4	26,476.0	26,212.9	39,477.3 8,132.3
3,092.4	3,500.3	3,052.9	2,895.0	3,921.4
283.7	289.5	277.9	265.8	318.5
48.7	50.0	46.2	46.1	112.1 52.6 29.0
	7,140.1 3,092.4 1,106.7 283.7 101.7	7,140.1 6,842.7 3,092.4 3,500.3 1,106.7 1,147.5 283.7 289.5 101.7 110.5 48.7 50.0	7,140.1 6,842.7 6,974.3 3,092.4 3,500.3 3,052.9 1,106.7 1,147.5 1,052.7 283.7 289.5 277.9 101.7 110.5 96.3 48.7 50.0 46.2	7,140.1 6,842.7 6,974.3 6,726.9 3,092.4 3,500.3 3,052.9 2,895.0 1,106.7 1,147.5 1,052.7 1,026.4 283.7 289.5 277.9 265.8 101.7 110.5 96.3 101.6 48.7 50.0 46.2 46.1

^{*} Average from Table E-8

TABLE E-10

R

VISCOSITY OF SHELLDYNE-H /DECALIN BLENDS AT VARIOUS TEMPERATURES

452.7 209.5	327.9 157.9	189.5
209.5	157.9	04.7
		94.7
138.4	106.9	62.5
76.3	60.8	38.3
34.2	26.3	19.2
17.9	15.5	11.6
10.9	8.8	7.4
7.4	6.1	5.5
	34.2 17.9 10.9	34.2 26.3 17.9 15.5 10.9 8.8

APPENDIX F

CALCULATED DENSITIES AND HEATS OF COMBUSTION FOR THE VARIOUS BLENDS

This section contains the calculated densities and heats of combustion for the various test mixtures. It has been assumed that these hydrocarbons form ideal solutions when mixed. The pure component densities and heats of combustion were extracted from handbooks, when available, or were measured in the petroleum laboratory.

Following are the pure component values for specific gravity, density and the net heat of combustion.

<u>Fluid</u>	Specific Gravity	Density @60°F Pounds/Gallon	Net Heat of Comb. Btu/Lb
Shelldyne-H®	1.065	8.859	17,890
Toluene	0.873	7.262	17,412
JP-4	0.755	6.280	18,840
Methylcyclohexane	0.776	6.455	18,790
Tetralin	0.975	8.110	17,390
t-Decalin	0.870	7.236	18,340
TH-MCPD Dimer	0.925	7.694	17,925
Iso-Butylbenzene	0.860	7.155	17,834

Figures F-1 through F-7 are plots of the densities and heats of combustion for the various binary mixtures of the hydrocarbons in Shelldyne-H®. From Figures F-1 through F-7, the densities and heats of combustion for the blends evaluated in this program were determined. These data are presented in Table F-1.

The data in Table F-1 were then used to obtain the plots in Figures F-8 through F-14 where the calculated volumetric net heats of combustion are plotted vs. the volumetric percentage of diluents for the binary mixtures of interest in this program.

TABLE F-1


THE CALCULATED DENSITIES AND HEATS OF COMBUSTION OF THE VARIOUS TEST DILUENTS IN SHELLDYNE-H


17																						
	OF COMBUSTION	Btu/Gallon	157,509	155,768	150,707	147,818	142,631	157,063	155,253	149,445	144,496	139,534	157,142	155,316	149,785	146.317	140,721	158,201	157,236	154,504	152,749	150,192
	-	Btu/1b	17,870	17,841	17,770	17,721	17,650	17,938	17,988	18,138	18,238	18,385	17,930	17,978	18,106	18,200	18,340	17,864	17,839	17,764	17,715	17.640
	Density Lbs/Gal	(60°F)	8.814	8.731	8.481	8.341	8.081	8.756	8.631	8.239	7,922	7,590	8.764	8.639	8.273	8.039	7.673	8.856	8.814	8.698	8.623	8.514
	Specific	Gravity	1.058	1.048	1.018	0.998	0.970	1.051	1.036	0.989	0.951	0.911	1.052	1.037	0.993	0.965	0.921	1.063	1.058	1.044	1.035	1.022
	Diluent Volume %	(60°F)	5.1	12.3	29.1	35.1	53.7	6.9	13.5	31.9	43.1	58.4	6.9	13.5	31.9	43.0	58.3	5.5	10.9	26.8	37.1	52.3
	Diluent	Weight %	5	01	25	35	20	2	10	25	35	50	ane 5	10	25	35	50	5	10	25	35	50
		Diluent	Toluene					JP-4					Methylcyclohexane					Tetralin				


AFAPL-TR-76-17


Diluent	Diluent Weight %	TABLE Diluent Volume % (60°F)	E F-1 (Cont'd) Specific Gravity	Density Lbs/Gal (60°F)	NET HEAT OF Btu/1b	F COMBUSTION Btu/Gallon
t-Decalin	25 25 35 50	5.9 11.9 29.0 39.7 54.8	1.058 1.048 1.018 0.997	8.814 8.731 8.481 8.306 8.064	17,911 17,933 18,002 18,047 18,115	157,063 156,571 152,674 149,899 146,087
TH-MCPD Dimer	50 35 50	5.7 11.5 27.8 38.3 53.9	1.060 1.052 1.031 1.016 0.994	8.831 8.764 8.589 8.464 8.281	17,906 17,922 17,973 18,006	158,125 157,072 154,374 152,408 149,522
Isobutyl-Benzene	25 35 35 50	6.2 12.3 29.6 40.3 55.8	1.057 1.045 1.012 0.992 0.961	8.805 8.706 8.431 8.264 8.006	17,887 17,884 17,876 17,870 17,862	157,511 155,696 150,712 147,684 143,005


AFAPL-TR-76-17






















FIGURE F-8. The Effect of Toluene Dilution on the Volumetric Heat of Combustion of Shelldyne-H.




117

FIGURE F-9. The Effect of JP-4 Dilution on the Volumetric Heat of Combustion of Shelldyne-H.



AFAPL-TR-76-17






Figure F-11. The Effect of Tetralin Dilution on the Volumetric Heat of Combustion of Shelldyne-H.




FIGURE F-12. The Effect of Trans Decalin on the Volumetric Heat of Combustion of Shelldyne-H.






FIGURE F-13. The Effect of TH-MCPD Dilution on the Volumetric Heat of Combustion of Shelldyne-H



122

FIGURE F-14. The Effect of Iso-Butylbenzene Dilution on the Volumetric Heat of Combustion of Shelldyne-H.



REFERENCES

- G. H. Ackerman, et al., "Hydrocarbon Fuels for Advanced Systems", U.S. Air Force Aero-Propulsion Laboratory Report Nr AFAPL-TR-70-71, Part 1, December 1970.
- 2. L. E. Faith, et al., "Hydrocarbon Fuels for Advanced Systems", U.S. Air Force Aero-Propulsion Laboratory Report Nr AFAPL-TR-70-71, Part 11, December 1971.
- 3. H. R. Lander, Jr. and M. J. Pedersen, "AF High Density Fuel Developments", 1973 JANNAF Propulsion Meeting, Specialist Session, Las Vegas, Nevada, November 1973.
- 4. U.S. Patent Nr 2,875,256 (24 Feb 59) Shell Development Company
- 5. U.S. Patent Nr 3,258,502 (28 Jun 66) Shell 0il Company
- 6. U.S. Patent Nr 3,282,663 (1 Nov 66) Shell Oil Company
- 7. U.S. Patent Nr 3,326,993 (20 Jun 67) Shell Oil Company
- 8. U.S. Patent Nr 3,329,732 (4 Jul 67) Shell Oil Company
- 9. U.S. Patent Nr 3,377,398 (9 Apr 68) Shell Oil Company
- 10. U.S. Patent Nr 3,326,992 (20 Jun 67) Shell Oil Company
- Belgian Patent Nr 614,967 (12 Sep 62) Shell Internationale Research Moatschappy N.V.
- 12. U.S. Patent Nr 3,140,275 (7 Jul 64) Shell Oil Company
- 13. West German Patent Nr 1239305 (27 Apr 67) Shell Internationale
- 14. Belgian Patent Nr 626,407 (21 Jun 63) Shell Internationale
- 15. C. W. Bird, et al., Tetrahedron Letters, 1961 (11), 373
- 16. J. J. Mrowca and T. J. Katz, J. Am. Chem Soc., 88, 4012 (1966)
- 17. D. M. Lernal and K. S. Shim, Tetrahedron Letters, 1961 (11), 368
- 18. D. R. Arnold, et al., J. Am. Chem Soc., 87, 2596 (1965)
- 19. R. J. Ouellette, et al., J. Am. Chem. Soc., 87, 2602 (1965)

- 20. T. J. Katz, et al., J. Org. Chem., 32, 1301 (1967)
- 21. G. E. Pollard, Spectrochim, Acta, 18, 837 (1962)
- 22. A. C. Mueller, P. Van Shaw, "Manufacture of a Hydrocarbon Fuel Shelldyne-H R", Shell Development Co. Report Nr S-14131, August 1972 (Distribution Limited).
- 23. A. C. Mueller, "Preparation of Shelldyne-H R An Experimental Hydrocarbon Fuel", U.S. Air Force Aero-Propulsion Report Nr AFAPL-TR-71-72, August 1971. (Distribution Limited)
- 24. Atlantic Research Corp., "Advanced Fuel Systems for Ramjet Powered Vehicles", U.S. Air Force Aero-Propulsion Report Nr AFAPL-TR-72-1, Vol. I and II, February 1972
- 25. J. R. Fultz, H. R. Lander, Jr., "RJ-5 (Shelldyne-H R) Type Fuels as Propellants for Volume Limited Air Breathing Missiles", Presentation 1972 JANNAF Propulsion Meeting, New Orleans, Louisiana, Nov 1972
- 26. Farol Research Engineers Ltd., Sussex, England, The Weissenberg Rheogoniometer (R-17) Instruction Manual
- 27. A. G. Frederickson, "Principles and Application of Rheology", Prentice-Hall, Inc., 1964
- 28. J. R. Van Wazer, "Viscosity and Flow Measurement", Interscience Publishers, 1963
- 29. R. D. Butler, "Chromatographic Examination of Shelldyne-H R and Related Materials", U.S. Air Force Aero-Propulsion Laboratory Report Nr AFAPL-SFF-TM-73-9
- 30. Aviation Week and Space Technology, 7 May 1973, 67